

TECHNICAL MANUAL

UNIT MAINTENANCE

FOR

**CONTAINER CRANE, 40-TON,
ROUGH TERRAIN, MODEL RT875CC
NSN 3810-01-205-5716**

This manual shall be used in place of the Unit maintenance portion of the GROVE Manufacturing Company Commercial Maintenance Manual No. 7-187-000004-2 dated 1 Feb 89 and the PAT Equipment Corp. Troubleshooting Manual DS350M dated January 1989v that were originally overpacked with the crane.

Approved for public release; distribution is limited

H E A D Q U A R T E R S , D E P A R T M E N T O F T H E A R M Y

25 FEBRUARY 1993

TECHNICAL MANUAL
HEADQUARTERS
No. 5-3810-306-20

DEPARTMENT OF THE ARMY
Washington D.C., 25 February 1993

UNIT MAINTENANCE MANUAL
FOR

CONTAINER CRANE, 40-TON
ROUGH TERRAIN, MODEL RT875CC
NSN 3810-01-205-2716

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: US Army Tank-Automotive Command, Attn: AMSTA-MB, Warren, MI 48090-5000.
A reply will be furnished to you.

TABLE OF CONTENTS

Page

CHAPTER 1.	INTRODUCTION	1-1
Section I.	General Information	1-1
	Scope	1-1
	Maintenance Forms, Records and Reports	1-1
	Destruction of Army Material to Prevent Enemy Use.....	1-1
	Preparation for Storage or Shipment	1-1
	Reporting Equipment Improvement Recommendations (EIR)	1-2
	Warranty Information	1-2
Section II.	Equipment Description and Data.	1-3
	Equipment Characteristics, Capabilities and Features.....	1-3
	Location and Description of Major Components.	1-4
	Equipment Data	1-6
	Safety, Care and Handling	1-11
Section III.	Principles of Operation.....	1-12
	Introduction.....	1-12
	Engine Lubrication System	1-12
	Fuel System.....	1-14
	Cooling System.	1-17
	Electrical System.....	1-19

Approved for public release; distribution is unlimited.

*This manual shall be used in place of the Unit maintenance portion of the GROVE Manufacturing Company Commercial Maintenance Manual No. 7-187-000004-2 dated 1 Feb 89 and the PAT Equipment Corp. Troubleshooting Manual, DS350M dated January 1989 that were originally overpacked with the crane.

	Page
CHAPTER 1. INTRODUCTION (Cont'd)	
Section III. Principles of Operation (Cont'd)	
Air System.....	1-23
Hydraulic System.....	1-33
CHAPTER 2. CRANE MAINTENANCE INSTRUCTIONS.....	2-1
Section I. Repair Parts, Special Tools, TMDE, and Support Equipment.....	2-1
Common Tools and Equipment7	2-1
Special Tools, Repair Parts, TMDE, and Support Equipment.....	2-1
Section II. Service Upon Receipt	2-2
Summary	2-2
Unpacking	2-2
Checking Unpacked Equipment.....	2-2
Deprocessing Unpacked Equipment.....	2-2
Preliminary Servicing and Adjustment.....	2-3
Section III. Organizational Preventive Maintenance Checks and Services.....	2-6
General.....	2-6
Organizational Preventive Maintenance Checks and Services	2-6
CHAPTER 3. TROUBLESHOOTING	3-1
Introduction.....	3-1
Symptom Index ..	3-1
Engine	3-4
Cooling System	3-19
Electrical System	3-22
Transmission/Torque Converter.....	3-23
Brake System	3-24
Steering System	3-25
Hydraulic System.....	3-28
Cab Heater	3-52
STE/ICE.....	3-57

	Page
CHAPTER 4. ENGINE MAINTENANCE	4-1
Section I. Rocker Arm Maintenance	4-2
Valve Adjustment	4-2
Valve Cover Replacement	4-4
Section II. Engine Lubrication System Maintenance	4-5
Engine Oil Filter Replacement.....	4-5
Turbocharger Oil Return Line Replacement.....	4-6
CHAPTER 5. FUEL SYSTEM MAINTENANCE	5-1
Section I. Air Cleaner Maintenance.....	5-2
Air Cleaner and Piping.....	5-2
Air Cleaner Assembly.....	5-4
Section II. Fuel Tanks, Lines and Fittings Maintenance	5-7
Fuel Tank Installation	5-7
Fuel Line Replacement	5-9
Fuel Supply and Return Lines Replacement.....	5-10
Bleeding Fuel System.....	5-12
Section III. Fuel Filter Maintenance.....	5-13
In-Line Fuel Filter/Strainer Installation.....	5-13
Fuel Water Separator/Filter Replacement.....	5-15
Section IV. Engine Starting Aid Maintenance.....	5-16
Quick Start Starting Fluid/Cylinder Service	5-16
Quick Start Ether Valve and Tubing Replacement.....	5-17
Section V. Fuel Pump Maintenance	5-18
Fuel Pump Installation	5-18
Idle Speed Adjustment	5-20
CHAPTER 6. EXHAUST SYSTEM MAINTENANCE.....	6-1
Muffler and Pipe Replacement	6-2

	Page
CHAPTER 7. COOLANT SYSTEM MAINTENANCE	7-1
Section I. Radiator Maintenance	7-2
Coolant Overflow Tank.....	7-2
Radiator Fan and Fan Guard Replacement.....	7-4
Radiator Hose and Tube Replacement.....	7-6
Radiator, Mooring Bracket and Shroud Replacement.....	7-9
Section II. Water Manifold, Headers, Thermostat and Gaskets Maintenance.....	7-14
Coolant Filter Replacement.....	7-14
Thermostat Replacement.....	7-16
Turbocharger Aftercooler and Piping Replacement.....	7-19
Water Pump Installation	7-21
Section III. Fan Assembly Maintenance	7-22
Belt Tensioner Replacement	7-22
Fan Drive Belt Replacement	7-23
CHAPTER 8. ELECTRICAL SYSTEM MAINTENANCE	8-1
Section I. Alternator Maintenance	8-3
Alternator Installation.....	8-3
Section II. Starter Motor Maintenance.....	8-5
Starter Motor Installation	8-5
Section III. Instrument Panel Maintenance	8-7
Blackout Light (Military) Switch Replacement	8-7
Dual Air Pressure Gauge Replacement	8-8
LED Alert Module Replacement	8-10
Front Control Panel	8-11
Left Console Harness Installation.....	8-12
Right Console Harness Installation	8-14
AV Harness Installation	8-16
Gauge Replacement	8-17
Pushbutton Switch Replacement	8-19
'Rotary Switch Replacement	8-20
Side Console and Access Panel Replacement.....	8-21
Side Console Panel Light (Bulb) Replacement	8-23
Side Console Harness Installation.....	8-24

	Page
CHAPTER 8.	ELECTRICAL SYSTEM MAINTENANCE (Cont'd)
Distribution Panel Wire Harness Installation	8-26
Distribution Panel Installation	8-30
Stop Light Switch Replacement.....	8-31
Tachometer Replacement.....	8-32
Toggle Switch Replacement	8-34
Warning Buzzer Replacement.....	8-36
Turn Signal Control Replacement	8-37
 Section IV.	
Beacon Light Assembly Replacement	8-38
Vehicle Lights Maintenance.....	8-38
Blackout Light Replacement.....	8-40
Boom Floodlight Replacement	8-41
Cab Floodlight Replacement	8-42
Clearance Light Replacement	8-43
Headlight Replacement	8-44
Turn Signal Light Replacement	8-45
 Section V.	
Sending Units and Switches Maintenance.....	8-46
Oil Pressure Sender Replacement.....	8-46
Low Oil Pressure Switch Replacement	8-47
Tachometer Magnetic Sensor Replacement	8-48
Transmission Oil Temperature Sender Replacement	8-49
Transmission Oil Temperature Switch Replacement	8-50
DCA Fuel Pressure Transducer Replacement	8-51
High Coolant Temperature Switch Replacement	8-52
Coolant Temperature Sender Replacement	8-53
DCA Pulse Tach Sender Replacement	8-54
Cold Start Temperature Switch Replacement	8-55
DC Power Relay Replacement	8-56
DCA Pressure Differential Switch Replacement	8-57
Fuel Shutoff Solenoid Installation	8-58
Rear Wheels Not Centered Switch Installation	8-59
Elevation Swing Warning Switch Installation	8-60
Area Definition Switch Replacement	8-62
Emergency Steer Oil Pressure Switch Replacement	8-64
Hydraulic Oil Cooler Temperature Control Switch Replacement	8-65
Back-Up Light Oil Pressure Switch Replacement	8-67
Fuel Filter Cable Assembly	8-68
Fuel Pressure Cable Assembly	8-70
Pulse Tach Cable Assembly	8-72
VTM Power Cable Harness	8-74
Carrier Harness Installation	8-76
Superstructure Harness Installation	8-82
Blackout Light Harness Installation	8-86
Floodlight Harness Installation	8-89
Cab Interior Harness Installation	8-90

CHAPTER 8. ELECTRICAL SYSTEM MAINTENANCE (Cont'd)

Section VI.	Horn and Alarms Maintenance.....	8-94
	Backup Alarm Replacement	8-95
	Horn Replacement	8-94
Section VII.	Battery Maintenance	8-96
	Battery Replacement.....	8-96
	Battery Box Cover and Slave Receptacle Replacement.....	8-98
	Battery Box Replacement	8-101
	Emergency Steer Pump Box Replacement	8-103
	Emergency Steer Pump Cable(s) Replacement	8-105
	Battery Cable(s) Removal	8-107
	Ground Cable at Shunt.....	8-109
	Shunt Replacement	8-110

CHAPTER 9.	TRANSMISSION SHIFTER MAINTENANCE.....	9-1
	Transmission Shifter Replacement	9-2
	Transmission Shift Hydraulic Lines, Superstructure	9-4
	Transmission Shift Hydraulic Lines, Carrier	9-6
	Transmission Control Valve Replacement	9-8
	Transmission to Torque Converter Hydraulic Lines	9-10
	Torque Converter Oil Filter Assembly Installation.....	9-12
	Torque Converter Oil Filter Installation.....	9-14

CHAPTER 10.	PROPELLER SHAFT MAINTENANCE	10-1
	Propeller Shaft Replacement	10-2
	Propeller Shaft Repair	10-4

CHAPTER 11.	BRAKE AND AIR SYSTEM MAINTENANCE	11-1
--------------------	---	------

Section I.	Service Brakes Maintenance	11-2
	Air System Purge	11-2
	Brake Chamber Installation	11-4
	Brake Chamber Assembly.....	11-8

	PAGE
CHAPTER 11. BRAKE AND AIR SYSTEM MAINTENANCE (Cont'd)	
Section II.	
Air System Maintenance	11-12
Air Dryer Replacement.....	11-12
Air Dryer Desiccant Cartridge Replacement.	11-14
Air Governor Replacement.....	11-20
Air Reservoir Replacement	11-21
Air Valve Muffler Replacement	11-22
Automatic Drain Valve Replacement	11-23
Double Check Valve and Pressure Protection Valve Replacement.....	11-24
Foot Brake Control Valve Replacement.....	11-25
Low Pressure Indicator Switch Replacement.....	11-27
Park Brake Control Valve and Pressure Indicator Switch Replacement.....	11-28
Pressure Protection Valve Replacement	11-30
R-12 Relay Valve Replacement	11-31
Single Check Valve Replacement	11-32
Spring Brake Control Valve Replacement.....	11-33
Throttle Cylinder and Control Rod Replacement.....	11-35
Tire Inflation Assembly.....	11-37
Windshield Washer Valve Replacement	11-39
Foot Throttle Control Valve Replacement	11-40
Air Lines Replacement, Superstructure Carrier	11-42
CHAPTER 12. WHEELS AND TRACKS MAINTENANCE.....	12-1
Tire and Wheel Installation.....	12-2
Tire and Wheel Assembly	12-3
CHAPTER 13. STEERING SYSTEM MAINTENANCE.....	13-1
Section I.	
Steer Cylinder Maintenance.....	13-2
Steer Cylinder Installation.....	13-2
Section II.	
Front Steer Relief Valve Maintenance	13-4
Front Steer Relief Valve Replacement	13-4
Section III.	
Emergency Steering Pump Maintenance.....	13-5
Emergency Steering Pump Replacement	13-5

	PAGE
CHAPTER 14. FRAME MAINTENANCE.....	14-1
Section I. Pintle Hook Maintenance	14-2
Pintle Hook Installation.....	14-2
Pintle Hook Assembly.....	14-3
Section II. Outrigger Float Maintenance	14-5
Outrigger Float Assembly.....	14-5
CHAPTER 15. BODY, CAB, HOOD AND HULL MAINTENANCE.....	15-1
Section I. Cab Maintenance	15-2
Cab Acoustical Foam Installation	15-2
Window Glass Replacement.....	15-3
Cab Protective Grill Replacement	15-5
Door Assembly Replacement.....	15-6
Door Latch Assembly Replacement	15-7
Grabrails.....	15-9
Cab Front Panel Replacement.....	15-10
Cab Bottom Panel Replacement.....	15-11
Section II. Engine Hood Maintenance.....	15-12
Engine Access Doors Replacement	15-12
Engine Hood Replacement	15-14
Section III. Fender and Rear Decking Maintenance	15-16
Fender and Rear Decking Replacement.....	15-16
Section IV. Seat Assembly Maintenance.....	15-27
Operator Seat and Pedestal Assembly Removal	15-27
Operator Seat Assembly	15-29
Section V. Accessory Maintenance.....	15-30
Circulating Fan Replacement.....	15-30
Cab Counterbalance Cylinder Replacement.....	15-31
Cab Heater Fuel Tank Replacement.....	15-32
Cab Heater/Defroster Assembly Replacement	15-34
Domelight Replacement.....	15-36
Fire Extinguisher Installation.....	15-38
Skylight Wiper Motor Replacement.....	15-39

	Page
CHAPTER 15. BODY, CAB, HOOD AND HULL MAINTENANCE (Cont'd)	
Steering Wheel Removal.....	15-40
Rear View Mirror Replacement	15-41
Windshield Wiper Motor Replacement	15-42
Wiper Arm Replacement	15-43
Decal Replacement	15-45
CHAPTER 16. HYDRAULIC SYSTEM MAINTENANCE	16-1
Section I. Hydraulic Control Valve Maintenance.....	16-2
Hydraulic Control Valve Installation.....	16-2
Integrated Outrigger Control Valve Installation	16-4
Front and Rear Outrigger Control Valve Installation.....	16-6
Swing Brake Valve and Pedal Installation.....	16-8
Rear Axle Lockout Valve	16-10
Two-Position Selector Valve.....	16-12
Lift Cylinder Over-Center Valve Installation.....	16-14
Section II. Filter and Lines Maintenance.....	16-16
Axle Lockout Hydraulic Lines.....	16-16
Free Swing Hydraulic Lines.....	16-18
Front Steering Hydraulic Lines, Cab.....	16-20
Front Steering Hydraulic Lines, Carrier.....	16-22
Rear Steering Hydraulic Lines.....	16-24
Hoist Hydraulic Lines	16-26
Hydraulic Filter Replacement	16-29
Lift Cylinder Hydraulic Lines, Cylinders.....	16-30
Lift Cylinder Hydraulic Lines, Valves	16-32
Outrigger Lines	16-34
Supply, Pressure, and Return Lines, Carrier	16-38
Supply, Pressure, and Return Lines, Superstructure	16-40
Telescope Hydraulic Lines	16-44
Section III. Hydraulic Reservoir Maintenance	16-46
Emergency Hand Pump Installation	16-46
Hydraulic Reservoir Replacement.....	16-48
Section IV. Hydraulic System Maintenance.....	16-50
Draining and Flushing Hydraulic System.....	16-50
Bleeding Air from Hydraulic System.....	16-52
Hydraulic Control Valve Relief Setting Checks and Adjustment	16-54

	Page
CHAPTER 17. BOOM MAINTENANCE	17-1
Section I. Boom Assembly Maintenance.....	17-2
Auxiliary Boom Nose Installation	17-2
Overhaul Ball Installation	17-4
Overhaul Ball Assembly	17-5
Hook Block Installation.....	17-7
Boom Alignment	17-9
Section II. Hoist Maintenance	17-12
Hoist Cable Idler Installation.....	17-12
Main and Auxiliary Wire Rope Installation	17-13
Section III. Turntable Maintenance	17-15
Positive Swing Lock Control Cable Installation	17-15
Swing Motor Installation	17-17
CHAPTER 18. PREPARATION FOR STORAGE OR SHIPMENT.....	18-1
Introduction.....	18-2
Preservation, Packaging, Packing, Illustration, Marking, and Shipping Requirements	18-2
Short Term Storage.....	18-2
Long Term Storage	18-3
APPENDICES	
Appendix A References.....	A-1
Appendix B Maintenance Allocation Chart	B-1
Appendix C Expendable/Durable Supplies and Material List.....	C-1
Appendix D Illustrated List of Manufactured Items	D-1
Appendix E Torque Limits	E-1
ALPHABETICAL INDEX	INDEX-1
HYDRAULIC DIAGRAM	FO-1
WIRING DIAGRAM	FO-3

LIST OF TABLES

Table	Title	Page
2-1	Organizational Preventive Maintenance Checks and Services.....	2-9
3-1	Organizational Troubleshooting.	3-4

xi/xii Blank

CHAPTER 1

INTRODUCTION

Section I. GENERAL INFORMATION

SCOPE

Type of Manual: Organizational Maintenance

Model Number and Equipment Name:

RT875CC - Container Crane, Rough Terrain
Wheel Mounted, Hydraulic, Diesel Powered

Purpose of Equipment: Provides for 360 degree boom travel and 80, 000 lbs (40 Tons) lifting capacity in rough terrain conditions.

MAINTENANCE FORMS, RECORDS, AND REPORTS

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by DA PAM 738-750, The Army Maintenance Management System.

Accidents involving injury to personnel or damage to materiel will be reported on DA Form 285 (Accident Report) in accordance with AR385-40.

Explosives and ammunition malfunctions will be reported in accordance with AR75-1.

DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE

Demolition of materiel to prevent enemy use will be in accordance with the requirement of TM 750-244-3 (Procedures for Destruction of Equipment to Prevent Enemy Use for U.S. Army).

PREPARATION FOR STORAGE OR SHIPMENT

Before the Container Crane is stored for a long period of time, shipped to a distant location, or returned to service after a period of time, certain guidelines/procedures must be followed. Refer to Chapter 18, Preparation for Storage and Shipment.

REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR)

If your RT875CC Container Crane needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Put it on an SF 368 (Quality Deficiency Report). Mail it to us at U.S. Army Tank Automotive Command, Attn: AMSTA-QRT, Warren, MI 48090. We'll send you a reply.

WARRANTY INFORMATION

The RT875CC Rough Terrain Container Crane is warranted by Grove Manufacturing Company for 18 months. Warranty starts on the date found on DA Form 2410 or DA Form 2408-16 in the logbook. Report all defects in materiel or workmanship to your supervisor who will take appropriate action. Refer to Warranty Technical Bulletin TB 5-3810-306-14.

Section II. EQUIPMENT DESCRIPTION AND DATA

EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES

RT875CC Rough Terrain Container Crane

- Axle steering accomplished by utilizing hydraulic steer cylinders
- Welded steel frame
- Engine mounted at rear of crane
- Superstructure
- Sliding beam outriggers are integral with carrier frame
- Remote mounted six speed transmission
- Four-wheel drive

Capability and Features

- Automatic axle oscillation when superstructure travels more than 5 degrees from-travel position
- All crane functions controlled from cab
- Superstructure capable of 360 degree rotation in either direction
- Lifting is provided by main and auxiliary hoists
- Equipped with two section, trapezoidal boom
- Integral fifth wheel, to which rear axle is mounted, provides axle oscillation

LOCATION AND DESCRIPTION OF MAJOR COMPONENTS

Counterweight. Bolted onto turntable to be part of turntable assembly. Weighs 12, 500 pounds.

Hookblock. Provides lifting capability while boom is retracted. Capable of lifting 40 tons and utilizes one-piece pivot block with a safety latch.

Overball Ball. Mounted on the auxiliary boom-nose. Ball can be stored during travel. Capable of lifting 5 tons.

Hydraulic Tank. 165 gallon capacity. Supplies hydraulic oil to hydraulic valve banks. Located on right side of carrier frame. Uses a magnetized drain plug to collect metal particles in tank and a sight gauge to indicate oil level.

Rear Outrigger. Mounted on rear stabilizer box. Extends when selector valve in outrigger control panel is operated. Stabilizes rear portion of crane during lifting operations.

Diesel Engine. Cummins 6CTA8.3 turbocharged diesel engine. Speed is controlled by a foot operated air throttle valve. Access to engine is gained through two side doors in hood assembly.

