


TECHNICAL MANUAL

**UNIT, DIRECT SUPPORT
AND GENERAL SUPPORT MAINTENANCE MANUAL**

**HYDRAULIC EXCAVATOR
JOHN DEERE
MODEL 330LCR
NSN 3805-01-463-0805**



DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited.

Reproduced by permission of Deere & Company, Moline, IL © 2000.
All rights reserved.

HEADQUARTERS, DEPARTMENT OF THE ARMY

15 FEBRUARY 2000

Technical Manual
No. 5-3805-281-24-2

**HEADQUARTERS,
DEPARTMENT OF THE ARMY
Washington, DC, 15 February 2000**

**UNIT, DIRECT SUPPORT
AND GENERAL SUPPORT
MAINTENANCE MANUAL**

**HYDRAULIC EXCAVATOR
JOHN DEERE
MODEL 330LCR
NSN 3805-01-463-0805**

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this publication. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Submit your DA Form 2028-2 (Recommended Changes to Equipment Technical Publications), through the Internet, on the Army Electronic Product Support (AEPS) website. The Internet address is <http://aebs.ria.army.mil>. If you need a password, scroll down and click on "ACCESS REQUEST FORM". The DA Form 2028 is located in the ONLINE FORMS PROCESSING section of the AEPS. Fill out the form and click on SUBMIT. Using this form on the AEPS will enable us to respond quicker to your comments and better manage the DA Form 2028 program. You may also mail, fax or email your letter, DA Form 2028, or DA Form 2028-2 direct to: Commander, U.S. Army Tank-automotive and Armaments Command, ATTN: AMSTA-LC-CI, Rock Island, IL 61299-7630. The email address is AMSTA-LC-CI@ria.army.mil. The fax number is DSN 793-0726 or Commercial (309) 782-0726.

DISTRIBUTION STATEMENT A - Approved for public release; distribution is unlimited.

TABLE OF CONTENTS

TM 5-3805-281-24-1

- Chapter 1 Section 9000 General Information**
- Chapter 2 Section 9005 Operational Checkout Procedure**
- Chapter 3 Section 9010 Engine**
- Chapter 4 Section 9015 Electrical System**
- Chapter 5 Section 9020 Power Train**
- Chapter 6 Section 9025 Hydraulic System**
- Chapter 7 Section 9031 Air Conditioning System**
- Chapter 8 Section 9035 Arctic/Cold Weather Heater**

TABLE OF CONTENTS (Continued)

Chapter	Section	Page
Chapter 9	Section 01 Tracks Repair	
Chapter 10	Section 02 Axles and Suspension Systems Repair	
TM 5-3805-281-24-2		
Chapter 11	Section 04 Engine Repair	
	0400 Removal and Installation	11-1
	Essential Tools	11-1
	Service Equipment and Tools.....	11-2
	Other Material	11-4
	Specifications	11-5
	Engine	
	Remove.....	11-7
	Install	11-12
	Engine Oil Pan, Remove and Install.....	11-17
	Engine, Disassemble and Assemble.....	11-18
	Fuel Injection Pump	
	Remove and Install	11-19
	Repair	11-19
	Water Pump	
	Remove.....	11-19
	Install	11-22
	Thermostats	
	Remove and Test	11-24
	Install	11-26
	Fuel Supply Pump	
	Remove.....	11-26
	Install	11-27
	Fuel Injection Nozzles	
	Remove.....	11-28
	Install	11-30
	Bleed the Fuel System.....	11-34
	Remove and Install Arctic/Cold Weather Heater Fuel Supply Pump.....	11-35
	Clean the Engine Crankcase Ventilation Tube.....	11-35
	Check and Adjust Engine Valve Lash (Clearance)	11-36
	Starter, Remove and Install	11-39
	General Information	11-40
	Unified Inch Bolt and Cap Screw Torque Values	11-40
	Metric Bolt and Cap Screw Torque Values.....	11-40
	Engine Model Designation.....	11-41
	Engine Serial Number Plate Information	11-42
	General Engine Specifications (OEM Applications).....	11-43
	Fuels, Lubricants, and Coolant	11-45
	Diesel Fuel	11-45
	Lubricity of Diesel Fuels.....	11-46
	Engine Break-In Oil	11-47
	Diesel Engine Oil	11-48
	Extended Diesel Engine Oil Service Intervals	11-49
	Alternative and Synthetic Lubricants	11-49
	Mixing of Lubricants.....	11-50
	Grease.....	11-50
	Diesel Engine Coolant Recommendations	11-51
	Engine Coolant Specifications	11-52
	Testing Diesel Engine Coolant.....	11-55

TABLE OF CONTENTS (Continued)

	Page
Replenishing Supplemental Coolant Additives (SCAs)	
Between Coolant Changes	11-56
Operating in Warm Temperature Climates	11-57
Disposing of Coolant.....	11-58
Flush and Service Cooling System.....	11-59
Engine Mounting	11-61
Engine Repair Stand.....	11-61
Safety Precautions	11-62
Install Adapters on Engine Repair Stand.....	11-63
Engine Lifting Procedure	11-64
Clean Engine	11-65
Disconnect Turbocharger Oil Inlet Line.....	11-66
Mount Engine on Repair Stand	11-67
Engine Rebuild, Break-In, and Tune-Up	11-69
Engine Disassembly Sequence for Overhaul.....	11-69
Sealant Application Guidelines	11-70
6081 Engine Assembly Sequence After Overhaul	11-72
Engine Break-In Guidelines	11-73
Perform Engine Break-In	11-74
Check Crankcase Ventilation System.....	11-75
Check Air Intake System.....	11-76
Check Exhaust System	11-76
Check and Service Cooling System	11-77
Check Electrical System.....	11-79
Preliminary Engine Testing Before Tune-Up.....	11-80
General Tune-Up Recommendations	11-81
Dynamometer Test	11-82
Dynamometer Test Specifications (OEM Engines)	11-83
Effects of Altitude and Temperature on Engine Performance.....	11-83
Cylinder Head and Valves	11-84
Special or Essential Tools	11-84
Cylinder Head and Valves Specifications	11-88
Service Equipment and Tools.....	11-90
Other Material	11-91
Check and Adjust Valve Clearance	11-92
Check Valve Lift	11-94
Remove Cylinder Head	11-95
Head Gasket Joint Construction and Operation	11-98
Diagnosing Head Gasket Joint Failures.....	11-100
Head Gasket Inspection and Repair Sequence	11-104
Disassemble and Inspect Rocker Arm Shaft Assembly.....	11-106
Assemble Rocker Arm Shaft Assembly	11-108
Measure Valve Recess.....	11-109
Preliminary Cylinder Head and Valve Checks.....	11-110
Remove Valve Assembly	11-111
Inspect and Measure Valve Springs	11-112
Inspect Valve Spring Caps, Wear Caps, and Retainer Locks.....	11-113
Clean Valves	11-113
Inspect and Measure Valves.....	11-114
Grind (Reface) Valves.....	11-115
Inspect and Clean Cylinder Head	11-115
Check Cylinder Head Combustion Face Flatness	11-116
Measure Cylinder Head Thickness.....	11-117
Clean Valve Guides.....	11-118
Measure Valve Guides	11-118
Knurl Valve Guides.....	11-119

TABLE OF CONTENTS (Continued)

	Page
Clean and Inspect Valve Seats	11-119
Measure Valve Seats	11-120
Grind Valve Seats.....	11-121
Remove Valve Seat Inserts and Measure Bores in Cylinder Head.....	11-122
Install Valve Seat Inserts.....	11-123
Inspect and Clean Cylinder Head Nozzle Bore	11-123
Clean and Inspect Push Rods	11-125
Inspect and Clean Ventilator Outlet Hose	11-125
Clean and Inspect Top Deck of Cylinder Block.....	11-126
Measure Cylinder Liner Standout (Height Above Block).....	11-127
Assemble Valve Assembly.....	11-128
Install Cylinder Head and Cap Screws	11-130
Torque-to-Yield Flanged-Head Cap Screws—	
Grade 180 Marked “Special”	11-132
Install Rocker Arm Assembly	11-133
Complete Final Assembly of Injection Pump Side of Engine	11-134
Complete Final Assembly on Exhaust Manifold Side of Engine	11-135
Perform Engine Break-In	11-136
Cylinder Block, Liners, Pistons, and Rods	11-137
Special or Essential Tools	11-137
Service Equipment and Tools.....	11-142
Other Material	11-142
Cylinder Block, Liners, Pistons, and Rods Specifications	11-143
Preliminary Liner, Piston, and Rod Checks	11-146
Remove Pistons and Connecting Rod Assemblies	11-147
Measure Cylinder Liner Standout (Height Above Block).....	11-151
Remove Cylinder Liners	11-152
Deglaze Cylinder Liners.....	11-154
Clean Cylinder Liners	11-155
Disassemble Piston/Rod Assembly	11-155
Clean Pistons	11-156
Visually Inspect Pistons	11-157
Check Piston Ring Groove Wear	11-158
Inspect Piston Pin and Bore.....	11-160
Visually Inspect Cylinder Liners.....	11-161
Cylinder Liner Manufacturing Date Code Explanation.....	11-163
Determine Piston-to-Liner Clearance.....	11-164
Measure Liner Flange Thickness.....	11-166
Inspect and Measure Connecting Rod Bearings.....	11-167
Inspect Rod and Cap	11-169
Inspect Piston Pins and Bushings	11-171
Remove Piston Pin Bushing, Clean and Inspect Pin Bore.....	11-173
Install Piston Pin Bushing in Connecting Rod	11-174
Complete Disassembly of Cylinder Block (If Required)	11-175
Remove and Clean Piston Cooling Orifices	11-175
Inspect and Clean Cylinder Block	11-176
Measure Cylinder Block.....	11-178
Install Piston Cooling Orifices and Gallery Plugs.....	11-179
Recheck Cylinder Liner Standout (Height Above Block).....	11-180
Install Liner Shims—If Required	11-181
Install Packing on Cylinder Liner and O-Rings in Block.....	11-182
Install Cylinder Liner in Block.....	11-183
Install Piston and Connecting Rod	11-185
Torque-Turn Connecting Rod Cap Screws	11-188
Check Engine Rotation for Excessive Tightness.....	11-189
Complete Final Assembly	11-190

TABLE OF CONTENTS (Continued)

	Page
Crankshaft, Main Bearings, and Flywheel.....	11-191
Special or Essential Tools	11-191
Service Equipment and Tools.....	11-197
Other Material	11-198
Crankshaft, Main Bearings, and Flywheel Specifications.....	11-199
Crankshaft and Main Bearing Failure Analysis	11-202
Remove Crankshaft Rear Oil Seal and	
Wear Sleeve (With Oil Seal Housing Installed)	11-203
Crankshaft Rear Oil Seal and Wear Sleeve Handling Precautions.....	11-205
Install Crankshaft Rear Oil Seal and	
Wear Sleeve (Without Engine Disassembly).....	11-206
Inspect Vibration Damper	11-207
Check Crankshaft End Play.....	11-209
Remove Crankshaft Vibration Damper	11-209
Replace Crankshaft Front Oil Seal and	
Wear Sleeve (With Timing Gear Cover Installed on Engine)	11-210
Remove and Install Timing Gear Cover—	
Engine Installed in Vehicle (8000 Series Tractors)	11-215
Remove Timing Gear Cover—Engine Removed	11-216
Inspect and Measure Flywheel	11-217
Check Flywheel Housing Face Runout	11-217
Check Flywheel Face Flatness	11-218
Check Pilot Bearing Bore Concentricity	11-218
Remove Flywheel.....	11-219
Remove SAE 1 and SAE 2 Flywheel Housing.....	11-220
Remove SAE 3 Flywheel Housing.....	11-220
Replace Flywheel Ring Gear.....	11-221
Remove and Install Rear Oil Seal Housing—	
Engine Installed in Vehicle (8000 Series Tractors)	11-222
Remove Rear Oil Seal Housing—Engine Removed	11-223
Remove Main Bearing Caps.....	11-224
Check Main Bearing Oil Clearance.....	11-226
Remove Connecting Rod Caps and Remove Crankshaft	11-227
Inspect Crankshaft.....	11-228
Measure Assembled I.D. of Bearings and	
O.D. of Crankshaft Journals	11-229
Main Bearing Cap Line Bore Specifications.....	11-231
Thrust Bearing New Part Specifications	11-232
Crankshaft Grinding Guidelines.....	11-233
Crankshaft Grinding Specifications	11-234
Replace (Crankshaft) Oil Pump Drive Gear.....	11-235
Replace Crankshaft Gear	11-236
Inspect Thrust Bearings.....	11-237
Remove and Clean Piston Cooling Orifices	11-238
Inspect Main Bearings and Crankshaft.....	11-239
Install Crankshaft Rear Oil Seal Housing.....	11-241
Check Oil Seal Housing Runout.....	11-243
Crankshaft Rear Oil Seal and Wear Sleeve Handling Precautions.....	11-244
Install Crankshaft Rear Oil Seal and Wear Sleeve Assembly	11-245
Install Timing Gear Cover.....	11-247
Install Front Wear Sleeve	11-248
Install Crankshaft Front Oil Seal	
(With Timing Gear Cover Installed on Engine).....	11-249
Install Vibration Damper.....	11-250
Install SAE 3 Flywheel Housing	11-251
Install Flywheel	11-252

TABLE OF CONTENTS (Continued)

	Page
Install SAE 1 and SAE 2 Flywheel Housing	11-253
Complete Final Assembly	11-253
Camshaft and Timing Gear Train	11-254
Special or Essential Tools	11-254
Other Material	11-258
Camshaft and Timing Gear Train Specifications	11-259
Camshaft and Timing Gear Train Torques.....	11-260
Check Valve Lift.....	11-261
Check Camshaft End Play and Measure Gear Backlash	11-262
Remove Vibration Damper and Timing Gear Cover.....	11-263
Remove, Inspect, and Install Camshaft	
Gear-Driven Auxiliary Drive—if Equipped	11-264
Remove Camshaft	11-265
Remove Camshaft Gears	11-267
Measure Thrust Washer Thickness	11-268
Inspect and Measure Camshaft Followers.....	11-268
Visually Inspect Camshaft.....	11-269
Measure Camshaft Journal O.D. and Bushing I.D.	11-269
Measure Camshaft Lobe Lift.....	11-270
Install Camshaft Gears	11-271
Service Camshaft Bushings Using JDG602 Adapter Set	11-272
Service Camshaft Bushings Using JDG606 Adapter Set	11-274
Install Camshaft.....	11-276
Install Thrust Washer and Timing Gear Cover	11-277
Complete Final Assembly	11-278
Lubrication System.....	11-279
Other Material	11-279
Lubrication System Specifications	11-280
Diagnosing Lubrication System Malfunctions	11-282
Oil Filter Base and Oil Pressure Regulating	
Valve Housing Assembly	11-283
Remove and Install Oil Filter Base and	
Oil Pressure Regulating Valve Housing	11-284
Engine Oil Cooler Assembly.....	11-285
Remove, Inspect, and Install Engine Oil Cooler	11-286
Remove, Inspect, and Install Oil Pressure Regulating Valve,	
Oil Filter Bypass Valve, and Oil Cooler Bypass Valve	11-288
Remove Engine From 8000 Tractors for Access to Engine Oil Pump ...	11-289
Remove Oil Pan	11-289
Check Crankshaft Gear-to-Oil Pump Drive Gear Backlash	11-290
Remove Engine Oil Pump	11-290
Inspect and Clean Oil Pump	11-291
Check Drive Shaft End Play	11-292
Check Drive Shaft Side Movement	11-292
Check Pumping Gear Backlash	11-293
Inspect Oil Pump Drive Gear	11-293
Adjust Oil Pump Set Screw (Early Engines).....	11-294
Install Engine Oil Pump	11-295
Remove and Install Oil Pump Outlet Tube and	
Oil Cooler Crossover Tube Adapter	11-296
Install Engine Oil Pan	11-297
Tighten Cap Screws on Front Frame/Oil Sump	
(8000 Series Tractors).....	11-299
Cooling System.....	11-301
Special or Essential Tools	11-301
Other Material	11-301

TABLE OF CONTENTS (Continued)

	Page
Cooling System Specifications.....	11-302
Diagnosing Cooling System Malfunctions.....	11-303
Replace Bearings in Heavy-Duty, Adjustable Fan Drive Assembly	11-304
Replace Bearings in Water Manifold-Mounted,	
Fixed Fan Drive Assembly	11-308
Checking Belt Tensioner Spring Tension and Belt Wear.....	11-310
Inspect and Install Fan Assembly.....	11-311
Visually Inspect Water Pump.....	11-312
Remove Water Pump Assembly.....	11-312
Install Water Pump Assembly.....	11-315
Replace Bypass Tube Seal in Water Pump Cover.....	11-316
Remove and Test Thermostats	11-317
Install Thermostats	11-318
Remove Water Manifold	11-318
Install Water Manifold	11-319
Servicing of Engine Coolant Heater.....	11-319
Complete Final Assembly	11-320
Air Intake and Exhaust System.....	11-321
Special or Essential Tools	11-321
Other Material	11-321
Air Intake and Exhaust System Specifications.....	11-322
Extending Turbocharger Life	11-323
Remove Turbocharger.....	11-325
Turbocharger Failure Analysis.....	11-326
Turbocharger Seven-Step Inspection	11-329
Perform Radial Bearing Clearance Test.....	11-336
Perform Axial Bearing End Play Test	11-337
Repair Turbocharger	11-338
Disassemble Turbocharger	11-339
Clean and Inspect Turbine and Compressor Housing	11-340
Replace Center Housing Assembly and Assemble Turbocharger.....	11-341
Prelube Turbocharger	11-342
Turbocharger Wastegate (If Equipped)	11-343
Install Turbocharger	11-344
Remove, Inspect, and Install Exhaust Manifold.....	11-346
Remove, Inspect, and Install Intake Manifold (6081T and 6081H Engines).....	11-347
Remove Vertically-Mounted Aftercooler and Intake Manifold (6081A Engines)	11-348
Remove and Disassemble Horizontally-Mounted Aftercooler (6081A Engines).....	11-350
Inspect and Repair Aftercooler (6081A Engines)	11-351
Inspect and Repair Intake Manifold and Air Intake Cover (6081A Engines)	11-352
Install Intake Manifold and Vertically-Mounted Aftercooler (6081A Engines).....	11-353
Assemble and Install Horizontally-Mounted Aftercooler Assembly (6081A Engines).....	11-356
Fuel System	11-358
Special or Essential Tools	11-358
Service Equipment and Tools.....	11-362
Other Material	11-363
Fuel System Specifications	11-364
Diagnosing Fuel System Malfunctions	11-365
Relieve Fuel System Pressure	11-365
Replace Rectangular Fuel Filter Element.....	11-366

TABLE OF CONTENTS (Continued)

	Page
Replace Fuel Filter Check Valve.....	11-367
Replace Primary (Round) Fuel Filter/Water Separator	11-368
Identification of Fuel Supply Pumps.....	11-369
Remove Fuel Supply Pump.....	11-369
Test Fuel Supply Pump for Leaks	11-370
Inspect Fuel Supply Pump.....	11-371
Install Fuel Supply Pump	11-372
Repair Injection Pump Aneroid—If Equipped	11-373
Remove Hydraulic Aneroid Activator—If Equipped.....	11-373
Disassemble and Clean Hydraulic Aneroid Activator Parts—If Equipped	11-374
Assemble and Install Hydraulic Aneroid Activator—If Equipped.....	11-374
Service Injection Pump Overflow Valve.....	11-375
Remove and Install Fuel Shutoff Solenoid—If Equipped	11-376
Identification of In-Line Fuel Injection Pumps	11-377
Service of Fuel Injection Pumps.....	11-378
Remove Fuel Injection Pump	11-378
Install Fuel Injection Pump	11-382
Remove Fuel Injection Nozzles.....	11-386
Diagnose Injection Nozzle Malfunction.....	11-388
Test Fuel Injection Nozzles	11-389
Perform Opening Pressure Test.....	11-390
Injection Nozzle Opening Pressure Specifications.....	11-391
Perform Nozzle Leakage Test	11-392
Perform Chatter and Spray Pattern Test	11-393
Disassemble Fuel Injection Nozzle	11-394
Clean and Inspect Fuel Injection Nozzle Assembly	11-396
Perform Nozzle Slide Test	11-397
Clean Spray Orifices	11-397
Inspect Nozzle Holder	11-398
Inspect Gland Nut.....	11-400
Assemble Fuel Injection Nozzle	11-401
Test and Adjust Injection Nozzle Opening Pressure	11-404
Inspect and Clean Cylinder Head Nozzle Bore	11-405
Inspect and Clean Nozzle Seating Surface	11-406
Install Fuel Injection Nozzles	11-406
Electrical System and Electrical Engine Controls	11-411
Special or Essential Tools	11-411
Other Material	11-414
Torques.....	11-414
Remove and Install Alternator (OEM Engines)	11-415
Remove and Install Starting Motor (OEM Engines)	11-416
Electronic Engine Control System and Sensors (Deere ECU Shown) ...	11-417
Remove and Install Sensors	11-418
Engine Control Unit (ECU).....	11-419
Transient Voltage Protection (TVP) Module	11-419
Connectors.....	11-420
Using High-Pressure Washer	11-420
Replace WEATHER PACK™ Connector.....	11-421
Install WEATHER PACK™ Contact.....	11-422
Remove Connector Body from Blade Terminals	11-424
Replace (Pull Type) Metri-Pack™ Connectors	11-425
Replace (Push Type) Metri-Pack™ Connectors	11-426
Use Electrical Insulating Compound.....	11-426
Replace DEUTSCH™ Connectors	11-427
Install DEUTSCH™ Contact.....	11-429

TABLE OF CONTENTS (Continued)

Chapter 12 Section	05 Engine Auxiliary Systems Repair	Page
	Dealer Fabricated Tools.....	11-431
	How to Make Tools.....	11-431
	DFRG3—Cylinder Liner Holding Fixture	11-431
Chapter 12 Section	05 Engine Auxiliary Systems Repair	
0505B	Cold Weather Starting Aids.....	12-1
	Engine Coolant Heater	
	Remove and Install	12-1
	Disassemble and Assemble.....	12-3
0510	Cooling System.....	12-5
	Service Equipment and Tools.....	12-5
	Specifications	12-5
	Fan, Shroud, and Guards—Remove and Install	12-6
	Radiator and Oil Cooler, Remove and Install.....	12-7
	Radiator and Oil Cooler Assembly, Disassemble and Assemble	12-10
	Coolant Expansion Tank, Remove and Install	12-11
	Fan and Air Conditioner Belts, Remove and Install.....	12-13
0515	Speed Controls.....	12-14
	Service Equipment and Tools.....	12-14
	Specifications	12-16
	Injection Pump Fast and Slow Idle Stops Adjustment	12-17
	Engine Speed Control Cable, Remove and Install.....	12-21
	Engine Control Motor, Remove and Install.....	12-22
	Engine Control Motor and Sensor Adjustment	12-23
	Engine Speed Learning Procedure	12-24
	Fuel Shut-Off Solenoid, Remove and Install.....	12-26
	Fuel Shut-Off Solenoid Linkage Check and Adjustment	12-27
0520	Intake System	12-29
	Essential Tools	12-29
	Service Equipment and Tools.....	12-29
	Specifications	12-29
	Air Intake System Leakage Test.....	12-30
	Air Cleaner, Remove and Install	12-31
	Charge Air Cooler, Remove and Install	12-32
0530	External Exhaust Systems.....	12-37
	Remove and Install Muffler	12-37
0560	External Fuel Supply Systems	12-38
	Other Material	12-38
	Specifications	12-38
	Fuel Tank, Remove and Install.....	12-39
	Primary Fuel Filter (Water Separator)	
	Remove and Install	12-40
	Disassemble and Assemble.....	12-42
	Final Fuel Filter Element, Replace	12-43
	Final Fuel Filter Check Valve, Replace	12-44
	Bleed the Fuel System.....	12-45
Chapter 13 Section	07 Dampener Drive (Flex Coupling) Repair	
0752	Elements	13-1
	Other Material	13-1
	Specifications	13-1
	Dampener Drive (Flex Coupling), Remove and Install.....	13-2
Chapter 14 Section	08 Splitter Drive Repair	
0800	Removal and Installation	14-1
	Other Material	14-1

TABLE OF CONTENTS (Continued)

Chapter 15 Section	16 Electrical System Repair	Page
	Splitter Housing Remove and Install 14-1 Disassemble 14-4 Assemble 14-9	
Chapter 15 Section	16 Electrical System Repair	
1671	Batteries, Support, and Cables Service Equipment and Tools 15-1 Specifications 15-2 Handle Batteries Safely 15-3 Procedure for Testing Batteries 15-4 Electrolyte Specific Gravity, Checking 15-5 Battery, Check Electrolyte Level and Terminals 15-7 Using Booster Batteries—24-Volt System 15-9 Battery, Charge 15-10 Engine Speed Learning Procedure 15-12 Batteries, Remove and Install 15-14 Adding 12-Volt Accessories 15-15 Remove and Install 24-Volt Slave Receptacle 15-16	15-1
1672	Alternator, Regulator, and Charging System Wiring Specifications 15-17 Alternator, Remove and Install 15-18 Special or Essential Tools 15-20 Robert Bosch Charging Circuit Specifications 15-21 Alternator, Section View 15-22 Alternator—Removal 15-22 Removing Brush Holder With Regulator 15-23 Alternator—Disassembly 15-23 Stator—Removal 15-23 Diode Plate—Removal 15-23 Alternator, Exploded View 15-24 Testing Rotor for Short Circuit 15-25 Testing Rotor for Ground 15-25 Testing Slip Rings and Rotor Shaft for Radial Runout 15-25 Turning Down Slip Rings 15-26 Testing Stator Coil for Short Circuit 15-26 Testing Stator Coil for Grounds 15-26 Replacing Carbon Brushes 15-27 Replacing Ball Bearings 15-27 Checking Positive Diodes 15-27 Checking Negative Diodes 15-28 Testing Exciting Diodes 15-28 Diode Plate Installation 15-29 Soldering Stator Coils 15-29 Pressing Ball Bearing Onto Rotor Shaft 15-29 Pressing Rotor Into Drive End Frame 15-30 Alternator—Assembly 15-30 Installing Brush Holder With Regulator 15-30 Fan and Belt Pulley—Installation 15-30	15-17
1674	Wiring Harness and Switches Essential Tools 15-31 Specifications 15-32 Functional Schematic and Component Location Legend 15-33 Cab Component Location Drawing 15-37 Engine and Pump Controller (EPC) Harness Connector, Connecting 15-38 Spring Wire Retainer Connectors, Disconnecting 15-38	15-31

TABLE OF CONTENTS (Continued)

	Page
Tab Retainer Connectors, Disconnecting	15-39
Fuses, Replacing.....	15-39
Fuse (Blade-Type) Color Codes.....	15-41
Cab Ground Straps, Remove and Install	15-41
Starter Switch, Remove and Install	15-42
Engine Speed Learning Procedure	15-43
Dome Light Switch, Remove and Install.....	15-45
Travel Alarm Cancel Switch and Start Aid Switch, Remove and Install.....	15-46
Replace DEUTSCH™ Connectors	15-46
Install DEUTSCH™ Contact.....	15-48
Replace WEATHER PACK™ Connector.....	15-49
Install WEATHER PACK™ Contact.....	15-51
Remove Connector Body from Blade Terminals	15-52
Remove and Install Hydraulic Oil Filter Restriction Switch	15-53
Overload Alarm Relay	15-54
Overload Alarm Pressure Switch.....	15-55
Overload Alarm Proximity Switch	15-56
Auxiliary Hydraulic Control Switch.....	15-56
1675 System Controls.....	15-57
Specifications	15-57
Welding on Machine	15-57
Engine Speed Learning Procedure	15-59
Engine and Pump Controller (EPC) Harness Connector, Connecting....	15-61
Engine and Pump Controller (EPC), Remove and Install	15-62
Monitor Controller, Remove and Install.....	15-63
1676 Instruments and Indicators.....	15-64
Replace Monitor Panel and Switch Panel Bulb.....	15-64
Monitor Panel, Remove and Install	15-64
Hour Meter, Remove and Install	15-66
Propel Alarm Volume, Changing.....	15-66
1677 Starting Motors	15-67
General Information	15-67
Typical Starting Circuit Operation	15-67
Typical Starting Motor Operation	15-68
Special or Essential Tools	15-69
Robert Bosch Starting Motor Specifications	15-70
Make No-Load Test	15-71
Diagnosing Starting Motor Malfunctions.....	15-72
Robert Bosch Starting Motor	15-73
Starting Motor, Exploded View	15-74
Disassembly	15-75
Solenoid Switch—Removal	15-75
Carbon Brush Plate—Removal	15-75
Armature—Removal	15-76
Snap Ring—Removal.....	15-76
Cleaning Parts	15-76
Testing Armature for Grounds	15-76
Testing Armature for Short Circuit	15-77
Testing Armature for Open Circuit	15-77
Turning Commutator Down	15-78
Testing Commutator for Out-of-Roundness.....	15-78
Testing Field Winding for Ground Circuits	15-79
Field Winding—Removal	15-79
Make Open Circuit Test for Field Windings	15-80

TABLE OF CONTENTS (Continued)

Chapter 16 Section	17 Frame or Supporting Structure Repair	Page
	Lubrication of Starting Motor (Before and During Assembly)	15-80
	Field Winding—Installation.....	15-81
	Checking Carbon Brush Plate for Grounds.....	15-81
	Testing Carbon Brushes	15-82
	Replace Carbon Brushes	15-82
	Engaging Lever—Installation	15-82
	Testing Armature End Play	15-83
	Installing Starting Motor	15-83
Chapter 16 Section	17 Frame or Supporting Structure Repair	
1740	Frame Installation	16-1
	Specifications	16-1
	Welding on Machine	16-1
	Welding Repair of Major Structure.....	16-3
1749	Chassis Weights.....	16-4
	Service Equipment and Tools.....	16-4
	Specifications	16-4
	Counterweight, Remove and Install	16-5
Chapter 17 Section	18 Operator's Station Repair	
1800	Removal and Installation	17-1
	Specifications	17-1
	Cab, Remove and Install	17-1
1810	Operator Enclosure	17-6
	Other Material	17-6
	Windowpane	
	Remove and Install Two Piece Molding.....	17-6
	Remove and Install One Piece Molding	17-8
	Sliding Windows, Remove and Install	17-9
	Windowpane Dimensions.....	17-10
1821	Seat and Seat Belt	17-12
	Specifications	17-12
	Seat	
	Check Adjustments	17-12
	Remove and Install	17-13
	Seat Belt	
	Remove and Install	17-19
	Inspect.....	17-20
1830	Heating and Air Conditioning	17-21
	Essential Tools	17-21
	Service Equipment and Tools.....	17-22
	Other Material	17-24
	Specifications	17-25
	Proper R134a Refrigerant Handling	17-25
	R134a Refrigerant Cautions	17-26
	R134a Compressor Oil	
	Charge Check.....	17-27
	Removal.....	17-27
	R134a Component Oil Charge	17-28
	R134a Refrigerant Recovery, Recycling and Charging	
	Station Installation Procedure	17-29
	R134a System	
	Recover.....	17-30
	Evacuate.....	17-31
	Charge.....	17-32
	Heater Core and Blower Motor, Remove and Install	17-33

TABLE OF CONTENTS (Continued)

		Page	
Heater Hoses, Remove and Install.....		17-35	
Air Conditioning Compressor			
Remove and Install		17-38	
Disassemble and Inspect.....		17-39	
Assemble		17-50	
Inspect Manifolds		17-53	
Remove and Install			
Receiver Dryer.....		17-54	
Evaporator		17-56	
Condenser		17-58	
Chapter 18	Section 19	Sheet Metal and Styling Repair	
1910		Hand Rails, Remove and Install	18-1
1919		Boom Cylinder Guard, Remove and Install.....	18-2
Chapter 19	Section 33	Excavator Repair	
3302		Buckets	19-1
Other Material		19-1	
Specifications		19-1	
Bucket Tooth, Replace		19-2	
Bucket Tooth Tip—Heavy-Duty Bucket, Replace.....		19-3	
Welding on Machine		19-4	
Tooth Shank, Remove and Install		19-5	
Welded Cutting Edge, Replace.....		19-9	
Cracked Cutting Edge, Repair.....		19-10	
Bucket, Disassemble and Assemble		19-11	
Quick-Disconnect Hitch			
Remove and Install		19-12	
Disassemble		19-14	
Assemble		19-16	
3340		Frames	19-19
Service Equipment and Tools.....		19-19	
Other Material		19-20	
Specifications		19-21	
Remove and Install			
Bucket Links.....		19-25	
Arm.....		19-26	
Boom		19-30	
Arm and Boom Pins and Bushings, Inspect		19-35	
Bushings and Seals, Remove and Install		19-37	
3360		Hydraulic System	19-38
Essential Tools		19-38	
Service Equipment and Tools.....		19-38	
Other Material		19-42	
Specifications		19-43	
Control Lever Pattern Conversion.....		19-52	
Hydraulic System Warm-Up Procedure		19-54	
Lower Boom With Engine Stopped (Using Boom Cylinder			
Load Lowering Valve).....		19-55	
Lower Boom With Engine Stopped (When Not Equipped			
With Boom Cylinder Load Lowering Valve)		19-57	
Hydraulic Oil Cleanup Procedure Using Portable Filter Caddy.....		19-59	
Hydraulic Pump, Remove and Install.....		19-60	
Start-Up Procedure, Hydraulic Pump and Splitter Drive		19-63	
Main Hydraulic Pump			
Disassemble		19-64	

TABLE OF CONTENTS (Continued)

	Page
Assemble	19-76
Hydraulic Pump Regulator, Disassemble and Assemble	19-85
Pilot Pump	
Remove and Install	19-89
Disassemble and Assemble.....	19-90
Pilot Pressure Regulating Valve and Filter	
Remove and Install	19-92
Disassemble and Assemble.....	19-94
Pilot Shut-Off Valve	
Remove and Install	19-94
Linkage Adjustment.....	19-96
Disassemble and Assemble.....	19-97
Proportional Solenoid Valve Manifold, Remove and Install.....	19-99
Proportional Solenoid Valve, Disassemble and Assemble.....	19-103
Dig Function Pilot Controller	
Remove and Install	19-106
Disassemble and Assemble.....	19-111
Propel Pilot Controller	
Remove and Install	19-114
Disassemble and Assemble.....	19-116
Flow Regulator Valve	
Remove and Install	19-119
Disassemble and Assemble.....	19-121
Control Valve	
Remove and Install	19-122
Disassemble and Assemble.....	19-130
Hydraulic Oil Tank	
Remove and Install	19-151
Disassemble and Assemble.....	19-158
Return Filter and Bypass Valve, Remove and Install.....	19-159
Suction Strainer, Remove and Install	19-162
Hydraulic Oil Tank Relief Valve and Breather Filter Cap,	
Disassemble and Assemble.....	19-164
Restriction Valve, Remove and Install	19-166
Oil Cooler Bypass Valve, Remove and Install	19-168
Radiator and Oil Cooler, Remove and Install.....	19-170
Radiator and Oil Cooler Assembly, Disassemble and Assemble	19-173
Boom Cylinder Controlled Load Lowering Valve, Remove	
and Install	19-174
Boom Cylinder, Remove and Install	19-176
Arm Cylinder, Remove and Install.....	19-180
Bucket Cylinder, Remove and Install.....	19-184
Hydraulic Cylinder Bleed Procedure.....	19-188
Boom, Arm or Bucket Cylinder	
Disassemble	19-189
Assemble	19-204
Auxiliary Hydraulics Pressure Reducing Valve	
Remove and Install	19-211
Disassemble and Assemble.....	19-212
Auxiliary Hydraulics Solenoid Control Valve	
Remove and Install	19-212
Disassemble and Assemble.....	19-213

TABLE OF CONTENTS (Continued)

			Page
Chapter 20	Section 33	Hydraulic Impact Breaker Repair	
	3302	Hydraulic Impact Breaker.....	20-1
		Hydraulic Impact Breaker	
		Disassembly.....	20-1
		Assembly	20-29
		Accumulator Assembly and Nitrogen Recharge	20-54
		Hydraulic Impact Breaker Set-Up and Oil Pressure Regulation	20-58
		Special Working Frequency Calibrations.....	20-65
		Hydraulic Circuit Adjustment	20-67
		Valves Calibration.....	20-68
		Technical Specifications.....	20-69
Chapter 21	Section 43	Swing or Pivoting System Repair	
	4350	Mechanical Drive Elements.....	21-1
		Service Equipment and Tools.....	21-1
		Other Material	21-3
		Specifications	21-4
		Swing Gearbox	
		Remove and Install	21-5
		Start-Up Procedure	21-8
		Disassemble and Assemble.....	21-9
		Upperstructure	
		Remove.....	21-19
		Install	21-24
		Swing Bearing	
		Remove and Install	21-28
		Disassemble and Assemble.....	21-29
		Install Upper Seal	21-33
		Install Lower Seal	21-34
	4360	Hydraulic System	21-35
		Specifications	21-35
		Swing Motor and Park Brake	
		Remove and Install	21-35
		Start-Up Procedure	21-37
		Disassemble	21-38
		Assemble	21-44
		Swing Motor Make-Up and Crossover Relief Valves,	
		Disassemble and Assemble.....	21-50
		Swing Motor Park Brake Relief Valve, Disassemble and Assemble	21-52
Chapter 22	Section 99	Dealer Fabricated Tools	
	9900	Dealer Fabricated Tools.....	22-1
		ST4920 Track Recoil Spring Disassembly and Assembly Tool	22-1
		DFT1087 Track Recoil Spring Disassembly and	
		Assembly Guard Tool.....	22-5
		DFT1112 Spacer	22-6
		DF1036A Propel Gearbox Nut Wrench	22-7
		DFT1109 Holding Bar	22-8
		DF1037 Hydraulic Pump Torque Adapter	22-9
		Rotary Manifold Lifting Tool.....	22-10
		DFT1089 Barrel Support.....	22-11
		Guide Pin.....	22-12
		DFT1119 Pump Support	22-13
Appendix A		Unit Preventive Maintenance Checks and Services (PMCS)	A-1
Appendix B		Maintenance Allocation Chart for Hydraulic Excavator 330LCR	B-1
Appendix C		References	C-1

BLANK

**CHAPTER 11
SECTION 04
ENGINE REPAIR**

Group 0400 Removal and Installation

ESSENTIAL TOOLS

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC).

SERVICEGARD is a trademark of Deere & Company.


CED,OUOE003,1129 -19-07JUL98-1/5

Load Positioning Sling D01043AA

T8015AG -UN-01JUN93

To remove engine.

T8015AG CV



04
0400
1

CED,OUOE003,1129 -19-07JUL98-2/5

Flywheel Turning Tool JDE81-1

To rotate crankshaft to position number one piston at "TDC" on compression stroke.

CED,OUOE003,1129 -19-07JUL98-3/5

Flywheel Turning Tool JDG820

T6585NO -UN-18OCT88

To rotate crankshaft to position number one piston at "TDC" on compression stroke.




CED,OUOE003,1129 -19-07JUL98-4/5

Timing Pin JDE-81-4

T6585NP -UN-18OCT88

To lock engine at TDC.



CED,OUOE003,1129 -19-07JUL98-5/5

*Removal and Installation***SERVICE EQUIPMENT AND TOOLS**

NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.

SERVICEGARD is a trademark of Deere & Company.

CED,OUOE003,1130 -19-07JUL98-1/8

M12 x 1.75 Metric Lifting Eyebolt JT05550

To support main hydraulic pump and splitter drive.

CED,OUOE003,1130 -19-07JUL98-2/8

Pump Support DFT1119¹

To support hydraulic pump and gearbox.

¹Fabricated tool, dealer made. (See Section 99 for instructions to make tool.)

CED,OUOE003,1130 -19-07JUL98-3/8

Crowsfoot Wrench. JDF22

To remove and install fuel injection lines and to tighten line nuts at delivery valves.

Continued on next page

CED,OUOE003,1130 -19-07JUL98-4/8

Removal and Installation

3/4 in. Line Wrench

To remove and install fuel injection lines and to tighten line nuts at delivery valves.

CED,OUOE003,1130 -19-07JUL98-5/8

Serrated Wrench. JDE90

To remove and install fuel injection lines and to tighten line nuts at delivery valves.

04
0400
3

CED,OUOE003,1130 -19-07JUL98-6/8

Nozzle Wrench. JDE92

To remove and install nozzles from cylinder head.

CED,OUOE003,1130 -19-07JUL98-7/8

24 mm (15/16 in.) Deep Socket

Used to remove nozzles.

CED,OUOE003,1130 -19-07JUL98-8/8

*Removal and Installation***OTHER MATERIAL**

Number	Name	Use
TY6299 (U.S.)	PERMATEX Aviation (Form-A-Gasket No. 3)	Apply to timing gear cover-to-cylinder block and rear oil seal housing-to-cylinder block mating surfaces.
PT569 (U.S.) TY6332 (Canadian)	NEVER-SEEZ® Anti-Seize Lubricant	Apply to fuel injection gland nut threads and nozzle barrel and to inside bore of gland nut.

04
0400
4

NEVER-SEEZ is a trademark of Emhart Chemical Group.

CED,OUOE003,1131 -19-07JUL98-1/1

*Removal and Installation***SPECIFICATIONS**

Item	Measurement	Specification	
Engine:			
Hydraulic Pump	Weight	111 kg (245 lb) approximate	
Engine	Weight	816 kg (1800 lb) approximate	
Front Engine Mount Bracket-to-Frame Cap Screw	Torque	390 N•m (290 lb-ft)	
Rear Engine Mount Bracket-to-Frame Cap Screw	Torque	300 N•m (225 lb-ft)	
Front Engine Mount Bracket-to-Engine Cap Screw	Torque	300 N•m (225 lb-ft)	04 0400 5
Rear Engine Mount Bracket-to-Engine Cap Screw	Torque	300 N•m (225 lb-ft)	
Main Hydraulic Pump and Splitter Drive-to-Flywheel Housing Cap Screw	Torque	88 N•m (65 lb-ft)	
Alternator (B+, WHT) Wire Nut	Torque	4 N•m (32 lb-in.)	
Alternator (D+, BLU/YEL) Wire Nut	Torque	2 N•m (20 lb-in.)	
Alternator (Ground, BLK) Wire Nut	Torque	2 N•m (20 lb-in.)	
Engine Oil Pan:			
Oil Pan-to-Cylinder Block Cap Screw (1/2 in.)	Torque	156 N•m (117 lb-ft)	
Oil Pan-to-Cylinder Block Cap Screw (3/8 in.)	Torque	68 N•m (50 lb-ft)	
Water Pump:			
Water Pump Cap Screw (3/8-in.)	Torque	47 N•m (35 lb-ft)	
Water Pump Cap Screw (5/16-in.)	Torque	27 N•m (20 lb-ft)	

Removal and Installation

Item	Measurement	Specification
Thermostat:		
Thermostat	Opening Temperature	89—100°C (192—212°F)
Thermostat Cover Cap Screw	Torque	47 N•m (35 lb-ft)
Fuel Injection Pump:		
Fuel Supply Pump Mounting Stud Nut	Torque	5—7 N•m (4—5 lb-ft) (45—60 lb-in.)
Fuel Injection Nozzle Gland Nut	Torque	88 N•m (65 lb-ft)
Fuel Injection Nozzle Line Nut	Torque	27 N•m (20 lb-ft)
Engine Valve:		
Intake Valve	Clearance	0.331—0.431 mm (0.013—0.017 in.)
Exhaust Valve	Clearance	0.661—0.761 mm (0.026—0.030 in.)
Valve Adjusting Screw Locknut	Torque	27 N•m (20 lb-ft)
Starter:		
Starter	Weight	23 kg (50 lb) approximate
Starter Cap Screw	Torque	47 N•m (35 lb-ft)

CED,OUOE003,1128 -19-07JUL98-2/2

Removal and Installation

REMOVE ENGINE

CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

1. Disconnect negative (-) battery cable.
2. Drain coolant. Cooling capacity is approximately 30 L (8 gal).




TS281 -UN-23AUG88

04
0400
7

TX,0400,DH5392 -19-15FEB97-1/8

3. Remove cap screws (A). Remove spring assembly (B).



T115283

T115283 -UN-17JUN98


A—Cap Screw (7 used)
B—Spring Assembly

Continued on next page

TX,0400,DH5392 -19-15FEB97-2/8

Removal and Installation

4. Remove cotter pin (D) and washer (E).
5. Remove support (C).
6. Remove cap screws (B). Remove engine cover (A).




T115284 -UN-17JUN98

T115284

- A**—Engine Cover
B—Cap Screw (4 used)
C—Support
D—Cotter Pin
E—Washer (2 used)

7. Remove clamps. Remove hoses (A—C).
8. Remove clamps. Remove cap screws (D). Remove air intake tube (E).
9. Remove coolant expansion tank (F). (See procedure in Group 0510.)



T115285 -UN-17JUN98


- A**—Charge Air Cooler-to-Turbocharger Hose
B—Charge Air Cooler-to-Intake Manifold Hose
C—Upper Radiator Hose
D—Cap Screw (2 used)
E—Air Intake Tube
F—Coolant Expansion Tank

Continued on next page

TX,0400,DH5392 -19-15FEB97-4/8

Removal and Installation

10. Remove speed control cable (A). (See procedure in Group 0515.)
11. Remove clamp. Remove lower radiator hose (C).
12. Remove water pump heater hose and engine block heater hose.
13. Remove clamps. Remove fuel supply line (D) and fuel return line (B).
14. Remove muffler. (See procedure in Group 0530.)
15. Remove air conditioning compressor belt. (See procedure in Group 0510.)
16. Remove air conditioning compressor. (See procedure in Group 1830.)



T115286 -UN-17JUN98


A—Speed Control Cable
B—Fuel Return Line
C—Lower Radiator Hose
D—Fuel Supply Line

04
0400
9

Continued on next page

TX,0400,DH5392 -19-15FEB97-5/8

Removal and Installation



T115653

T115653 - JUN-17 JUN 98

A—Oil Pressure Switch Connector	D—Start Solenoid Connector	G—Oil Level Switch Connector	I—Fuel Shutoff Solenoid Connector
B—Engine Temperature Switch Connector	E—Starter Motor (RED + Battery Cable)	H—Alternator (B+, WHT) (D+, BLU/YEL) (Ground, BLK)	
C—Engine Coolant Temperature Sender	F—Starter-to-Frame Ground Strap		

17. Disconnect connectors (A, B, D, G, and I).
18. Remove nut. Remove engine coolant temperature sender (C).
19. Remove nut. Remove starter motor RED positive battery cable (E).
20. Remove nut. Remove starter-to-frame ground strap (F).
21. Remove nuts. Remove alternator wires (H).

Continued on next page

TX,0400,DH5392 -19-15FEB97-6/8


Removal and Installation

! **CAUTION:** Hydraulic pump weighs approximately 111 kg (245 lb).

Hydraulic Pump—Specification

Weight..... 111 kg (245 lb) approximate

22. Install JT05550 Metric Lifting Eyebolts (A) into pump controller top plugs.
23. Support main hydraulic pump and splitter drive as shown using DFT1119 Pump Support and a small winch hoist.



T115287

A—Metric Eyebolts (2 used)

T115287 -UN-17JUN98

04
0400
11


TX,0400,DH5392 -19-15FEB97-7/8

! **CAUTION:** The approximate weight of engine is 816 kg (1800 lb).

Engine—Specification

Weight..... 816 kg (1800 lb) approximate

24. Attach D01043AA Load Positioning Sling to engine as shown.
25. Remove main hydraulic pump and splitter drive-to-flywheel housing cap screws.
26. Remove engine mount cap screws and nuts.
27. Raise engine slightly and push engine away from hydraulic pump. Lift engine when engine is disengaged from pump drive coupling.




T107725B -UN-27MAR97

TX,0400,DH5392 -19-15FEB97-8/8

Removal and Installation

INSTALL ENGINE



T115289

T115289 - JUN-17 JUN 98

A—Cap Screw (8 used)
 B—Washer (8 used)
 C—Cap Screw (2 used)
 D—Washer (2 used)
 E—Nut (2 used)
 F—Washer (2 used)

G—Stopper (2 used)
 H—Rubber (2 used)
 I—Rubber (2 used)
 J—Stopper (2 used)
 K—Bracket
 L—Cap Screw (8 used)

M—Washer (8 used)
 N—Cap Screw (2 used)
 O—Washer (2 used)
 P—Unit
 Q—Nut (2 used)
 R—Washer (2 used)

S—Stopper (2 used)
 T—Rubber (2 used)
 U—Rubber (2 used)
 V—Stopper (2 used)
 W—Bracket
 X—Bracket

1. Lower engine into excavator.