

TM 5-3810-289-34 CRANE-SHOVEL, CRAWLER MOUNTED; 12 ½ TON-1970

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

Direct Support And General Support
Maintenance Manual
CRANE-SHOVEL CRAWLER MOUNTED;
12 ½ -TON, ¾ -CU YD; DIESEL ENGINE
DRIVEN (BUCYRUS-ERIE MODEL 22BM)
FSN 3810-869-3092

HEADQUARTERS, DEPARTMENT OF THE ARMY
JUNE 1970



DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE MANUAL

**CRANE-SHOVEL, CRAWLER MOUNTED; 12 ½ -TON, ¾ CU. YD; DIESEL
ENGINE DRIVEN (BUCVRUS-ERIE MODEL 22 BM) FSN 3810-869-3092**

		Paragraph	Page
Chapter	1. INTRODUCTION		
Section	I. General.....	1-1 1-3	1-1
	II. Description and data	1-4 1-6	1-1
Chapter	2. DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE INSTRUCTIONS		
Section	I. Repair parts, special tools, and equipment	2-1 2-3	2-1
	II. Troubleshooting.....	2-4 2-5	2-2
	III. General maintenance instructions.....	2-6 2-8	2-3
	IV. Removal and installation of major components	2-9 2-10	2-22
Chapter	3. REPAIR OF ENGINE AND ACCESSORIES		
Section	I. Engine accessories	3-1 3-19	3-1
	II. Engine	3-20 3-48	3-36
Chapter	4. REPAIR OF CRANE SHOVEL UPPER WORKS AND LOWER WORKS		
Section	I. Upper works	4-1 4-14	4-1
	II. Lower works.....	4-15 4-24	4-26
Appendix	A. REFERENCES		
	Index		I-1

***This manual supersedes the direct support, general support and depot maintenance portions of TM 5-3810-289-15, 3 July 1968.**

LIST OF ILLUSTRATIONS

<i>Number</i>	<i>Title</i>	<i>Page</i>
2-1	Cab Assembly, exploded view	2-22
2-2	Engine assembly removal and installation	2-23
3-1	Alternator assembly. exploded view	3-2
3-2	Alternator test connections	3-3
3-3	Diode rectifier test	3-4
3-4	Fuel pump return line removal	3-4
3-5	Fuel supply line disconnection	3-4
3-6	Fuel pump removal	3-5
3-7	Fuel pump mounted to ST-546	3-5
3-8	Shutdown valve removal	3-7
3-9	Pulsation damper capscrew removal	3-6
3-10	Drive cover capscrews removal	3-6
3-11	Drive cover removal	3-8
3-12	Governor plunger removal	3-8
3-13	Throttle assembly removal	3-8
3-14	Gear pump removal	3-8
3-15	Spring pack cover removal	3-9
3-16	Spring pack assembly removal	3-9
3-17	Filter assembly removal	3-9
3-18	Tachometer drive assembly removal	3-9
3-19	Tachometer cover installation	3-9
3-20	Filter assembly installation	3-9
3-21	Washer being installed over plunger	3-10
3-22	Governor plunger installation	3-11
3-23	Governor idle plunger	3-11
3-24	Spring pack snap ring installation	3-11
3-25	Gear pump installation	3-11
3-26	Gear pump capscrews, torquing	3-11
3-27	Current PT (type G) throttle shaft	3-11
3-28	Throttle shaft O-ring installation	3-12
3-29	Snap ring installation	3-12
3-30	Governor plunger installation	3-12
3-31	Drive cover to main housing installation	3-13
3-32	Nylon buffer installation	3-13
3-33	Screw removal from shutdown valve	3-14
3-34	Electric shutdown valve. exploded view	3-14
3-35	"Plate type" valve inspection	3-14
3-36	Override shaft installation	3-14
3-37	Shaft tip depth check	3-14
3-38	Valve assembly	3-15
3-39	Housing, fuel pump-exploded view	3-15
3-40	Drive shaft bushing reaming	3-16
3-41	Pulsation damper, exploded view	3-16
3-42	Drive cover assembly pressed from front cover	3-16
3-43	Weight shaft assembly being pulled with ST-709	3-17
3-44	Snap ring removal from groove	3-17
3-45	Governor carrier weight assembly exploded view	3-17
3-46	Gear removal from weight carrier	3-18
3-47	Tachometer drive gear and governor drive gear being pressed	3-18
3-48	Drive bearing being pressed on shaft	3-18
3-49	Tachometer gear being pressed on drive shaft	3-18
3-50	Drive cover oil seal installation	3-19
3-51	ST419 oil seal tool assembled over main shaft	3-19
3-52	Snap ring secured in groove	3-19
3-53	Assist plunger installation	3-19
3-54	Assist plunger protrusion measurement	3-19
3-55	Torque spring removal	3-20
3-56	Governor plunger driver removal	3-20
3-57	Clearance check between washer and driver	3-21
3-58	Gear pump with integral cooling exploded view	3-21

<i>Number</i>	<i>Title</i>	<i>Page</i>
3-59	Gear width check	3-21
3-60	Gear pocket depth check	3-21
3-61	Locating notches	3-22
3-62	Gear pump capscrews torque	3-22
3-63	Automotive governor, exploded view	3-22
3-64	MVS governor PT (type G)	3-23
3-65	Fuel filter screen- MVS governor type	3-23
3-66	Governor plunger being lapped to barrel	3-24
3-67	Locking clip being removed from bottom of fuel pump housing	3-24
3-68	Canter line being scribed on governor barrel	3-25
3-69	Center line being scribed on fuel pump housing	3-25
3-70	Current PT (type Governor plunger	3-25
3-71	Spring dowel installation in bottom of fuel pump housing	3-26
3-72	Tachometer gear being pressed	3-26
3-73	Tachometer gear	3-26
3-74	Injector removal	3-27
3-75	Injector in ST%569 holding fixture	3-27
3-76	New injector cup tip	3-27
3-77	Worn injector cup tip	3-28
3-78	Corroded injector cup tip	3-28
3-79	Seat pattern of plunger in cup	3-28
3-80	Injector spring test	3-28
3-81	Injector spring	3-28
3-82	Plunger link wear	3-29
3-83	Pulling link with a tapholder	3-29
3-84	Plunger link assembly	3-29
3-85	Repairing inlet and drain connection surfaces with ST-542	3-29
3-86	Installing O-ring with assembly tool	3-29
3-87	Injector cup gasket markings	3-29
3-88	Size marking location on plunger	3-30
3-89	Size markings on injector body	3-30
3-90	Markings on injector cups	3-30
3-91	Injector cup wrenches	3-30
3-92	Installing injectors	3-31
3-93	Torquing injector holddown capscrew	3-31
3-94	Torquing fuel inlet and drain connections	3-31
3-95	Measuring injector tip protrusion	3-32
3-96	Sleeve seat bead and chamfer location	3-32
3-97	Installing injector sleeve	3-32
3-98	Sealing upper end of injector sleeve with ST-297	3-32
3-99	Sealing lower end of injector sleeve	3-33
3-100	ST-397-3 injector seat cutter dimensions	3-33
3-101	Clutch assembly. cutaway view	3-34
3-102	Fuel tank repair	3-35
3-103	Primer unit; lines, fittings, exploded view	3-35
3-104	Radiator repair	3-36
3-105	Water pump removal	3-36
3-106	Water pump, exploded view	3-37
3-107	Bearing and shaft assembly being pressed in	3-37
3-108	Mandrel being placed on seal driving lip	3-38
3-109	Water pump being secured to block	3-38
3-110	Fan hub assembly removal and installation	3-39
3-111	Fan hub assembly, exploded view	3-40
3-112	Accessory drive pulley removal	3-41
3-113	Pulley and sleeve	3-41
3-114	Accessory drive assembly, exploded view	3-42
3-115	Accessory drive pulley installation	3-43
3-116	Oil transfer connection, removal and installation	3-43
3-117	Water header plate, removal and installation	3-43
3-118	Cylinder head removal	3-44
3-119	Cylinder head in head holding fixture	3-44
3-120	Compressing valve springs with ST-448	3-44
3-121	Install injector sleeve holding tool S-, 383	3-45
3-122	Inspecting valve and injector port areas	3-45
3-123	Fuse plug location	3-45

<i>Number</i>	<i>Title</i>	<i>Page</i>
3-124	Inserting holddown knob into holder assembly	3-46
3-125	Setting reamer depth	3-46
3-126	Driving bushing into hole	3-46
3-127	Sand cylinder head	3-46
3-128	Check cylinder head height	3-46
3-129	Regroove/cylinder head	3-47
3-130	Installing grommets and retainers	3-48
3-131	Installing cylinder head gasket	3-48
3-132	Installing cylinder head	3-48
3-133	Cylinder head cover removal	3-49
3-134	Loosening rocker arm lever jam nuts	3-49
3-135	Cylinder head mounting capscrews removal	3-49
3-136	Rocker arm assembly removals	3-49
3-137	Crankcase breather-bottle stopper type	3-49
3-138	Magnetic inspection crack indication	3-50
3-139	Checking rocker lever adjusting screw ball end	3-50
3-140	Installing bushing with ST-49I	3-51
3-141	Rocker arm assembly, exploded view	3-51
3-142	Rocker arm assembly	3-52
3-143	Oil transfer dowel insertion	3-52
3-144	Cylinder head capscrew tightening sequence	3-52
3-145	Torquing cylinder head capscrews	3-52
3-146	Cylinder head cover installation	3-53
3-147	Push rod removal and installation	3-53
3-148	Checking push tube ball end with radius gage	3-54
3-149	Checking push rod socket end with adjusting screw	3-54
3-150	Minimum valve head rim thickness	3-54
3-151	Valve stem measurement	3-54
3-152	Valve guide measurement	3-55
3-153	Valve spring testing	3-55
3-154	Valve grinding	3-55
3-155	Pencil marks on valves	3-55
3-156	Reaming valve guide	3-56
3-157	Valve guide installation with ST-740	3-56
3-158	Tappet guide screw removal and installation	3-57
3-159	Tappet disassembly	3-57
3-160	Roller and pin installation	3-57
3-161	Tappet roller concentricity inspection	3-57
3-162	Tappet installation	3-58
3-163	Flywheel removal	3-58
3-164	Flywheel indicator gage installation	3-59
3-165	Flywheel indicator gage	3-59
3-166	Flywheel housing removal	3-59
3-167	Camshaft counterbore gasket installation	3-60
3-168	Flywheel housing indicator gage installation	3-60
3-169	Flywheel housing indicator gage	3-60
3-170	Oil pan, exploded view	3-61
3-171	Oil pan installation	3-62
3-172	Pan-to-block alignment check	3-62
3-173	Drain tube capscrews removal	3-62
3-174	Oil pump capscrews removal	3-62
3-175	Oil pump and suction tube installation	3-63
3-176	Crankshaft hub capscrew removal	3-63
3-177	Vibration damper removal and installation	3-64
3-178	Crankshaft hub removal	3-64
3-179	Crankshaft hub installation	3-64
3-180	Vibration damper installation	3-64
3-181	Vibration and crankshaft hub eccentricity and wobble measurements	3-64
3-182	Gear cover removal and installation	3-65
3-183	Gear cover trunnion bushing exploded view	3-65
3-184	Gear cover mounting plate removal	3-65
3-185	Gear cover mounting plate installation	3-66
3-186	Oil slinger capscrews removal	3-66
3-187	Camshaft removal	3-67
3-188	Camshaft journals measurement	3-67

<i>Number</i>	<i>Title</i>	<i>Page</i>
3-189	Camshaft gear key from gear case end	3-68
3-190	Securing camshaft bearing retainer to block	3-68
3-191	Checking camshaft gear backlash	3-68
3-192	Checking camshaft end play	3-69
3-193	Rear cover removal	3-69
3-194	Rear cover locating surface	3-69
3-195	Rear cover installation	3-70
3-196	Rear cover alinement check	3-70
3-197	Cleaning cylinder liner with emery cloth	3-70
3-198	Connecting rod cap removal	3-70
3-199	Reassembling cap to connecting rod	3-70
3-200	Connecting rod specifications	3-71
3-201	Connecting rod crank journal bore check	3-71
3-202	Connecting rod piston pin bushing check	3-72
3-203	Rod bore alinement check	3-72
3-204	Rod twist check	3-72
3-205	Ring groove wear check	3-72
3-204	Piston check points	3-73
3-207	Piston ring gap check	3-73
3-208	Piston pin bushing installation	3-74
3-209	Boring piston pin bushing on ST-526	3-74
3-210	Installing pin in piston and rod	3-75
3-211	Piston rings installation	3-75
3-212	Piston and rod assemblies installation	3-76
3-213	Connecting rod cap installation	3-76
3-214	Torquing connecting rod U-bolt nuts	3-76
3-215	Rod-to-crankshaft side clearance check	3-76
3-216	Prying main bearing caps loose	3-77
3-217	Removal of main bearing caps from block	3-77
3-218	Lift crankshaft from block	3-77
3-219	Drilling dowel hole in rear main bearing cap	3-78
3-220	Measuring thickness of bearing shell	3-78
3-221	Crankshaft gear removal with ring-type puller	3-78
3-222	Checking thrust flange for wear	3-78
3-223	Crank pin journal measurement	3-79
3-224	Cleaning drilled oil passages	3-79
3-225	Oversize thrust bearing size mark on crankshaft	3-79
3-226	Crankshaft dimension points	3-80
3-227	Crankshaft magnetic inspection	3-80
3-228	Upper main bearing shells installation	3-81
3-229	Crankshaft installation	3-82
3-230	Main bearing cap with thrust ring in place	3-82
3-231	Torquing main bearing capscrews	3-82
3-232	Checking crankshaft end play	3-83
3-233	Installing crankshaft oil seal with ST480	3-83
3-234	Cleaning block oil passages	3-84
3-235	Air bleed hole	3-84
3-236	Cleaning cylinder head capscrew holes	3-84
3-237	Checking camshaft bushing inside diameter	3-85
3-238	Cylinder liner counterbore dimensions	3-85
3-239	Inspecting liner of flange height-outside bead	3-86
3-240	Inspecting liner counterbore depth in block	3-86
3-241	Inspecting cylinder liner clearance	3-86
3-242	Checking main bearing bore alinement	3-86
3-243	Torquing main bearing capscrews	3-86
3-244	Checking main bearing bore for out-of-round	3-87
3-245	Tappet bore inside diameter check	3-87
3-246	Engine cylinder block components, exploded view	3-87
3-247	Camshaft bushing installation	3-88
3-248	Cylinder block height	3-88
3-249	Cylinder liner counterbore cross-section	3-88
3-250	Counter boring tool kit	3-88
3-251	Standard and oversize counterbore diameters	3-89
3-252	Reaming main bearing bore	3-89
3-253	Reaming eroded water hole	3-90

<i>Number</i>	<i>Title</i>	<i>Page</i>
3-254	Valve seat insert removal	3-90
3-255	Valve seat insert cross-section	3-90
3-256	Counterbore for valve seat insert	3-91
3-257	Refacing valve seat	3-91
3-258	Indicating valve seat insert	3-91
3-259	Valve crossheads removal	3-92
3-260	Pulling crosshead guide	3-92
3-261	Crosshead guide installation	3-92
3-262	Crosshead stem and guide alinement, cutaway view	3-93
3-263	Torquing crosshead adjusting screw locknuts	3-93
3-264	Pulling cylinder liner with ST-777 puller	3-93
3-265	Cylinder liner puller adapter plate	3-93
3-266	Cylinder liner bore inspection	3-94
3-267	Cylinder liner cross-section	3-94
3-268	Honing liner	3-95
3-269	Initial honing stone expansion	3-95
3-270	Cylinder liner counterbore inspection	3-96
3-271	Cylinder liner flange inspection	3-97
3-272	Cylinder liner installation	3-97
3-273	Cylinder liner bore inspection	3-97
3-274	Inspecting cylinder liner protrusion	3-97
4-1	Transmission shaft, exploded view	4-2
4-2	Front frame cover	4-3
4-3	Gear case sump	4-4
4-4	Vertical swing shaft	4-4
4-5	Cone roller replacement	4-4
4-6	Vertical propel shaft, exploded view	4-6
4-6	(sheet 1 of 3)	
4-6	Vertical propel shaft, exploded view	4-7
4-6	(sheet 2 of 3)	
4-6	Vertical propel shaft, exploded view	4-8
4-6	(sheet 3 of 3)	
4-7	Vertical swing shaft repair and replacement	4-9
4-8	Horizontal swing shaft, cutaway view	4-10
4-9	Rear drum shaft removal	4-11
4-10	Rear drum shaft shifter bridge and yoke	4-11
4-11	Rear and front drum shaft assembly, exploded view	4-13
4-11	(sheet 1 of 3)	
4-11	Rear and front drum shaft assembly. exploded view	4-14
4-11	(sheet 2 of 3)	
4-11	Rear and front drum shaft assembly, exploded view	4-15
4-11	(sheet 3 of 3)	
4-12	Rear drum shaft assembly (left side;	4-16
4-13	Rear drum shaft assembly (right side)	4-17
4-14	Rear drum shaft assembly	4-17
4-15	Front drum shaft removal	4-18
4-16	Boom hoist clutch and brake band removal and installation	4-18
4-17	Front drum shaft assembly, right side (sheet 1 of 2)	4-20
4-17	Font drum shaft assembly. right side (sheet 2 of 2)	4-20
4-18	Boom hoist safety pawl	4-21
4-19	Control levers	4-22
4-20	Independent boom hoist assembly, exploded view	4-24
4-21	Track drive sprocket replacement	4-29
4-22	Track belt removal and installation	4-29

CHAPTER 1
INTRODUCTION

Section I. GENERAL

1-1. Scope

a. This manual contains instructions for use by direct and general support maintenance personnel maintaining the Bucyrus Erie Model 22-BM Crane-Shovel. It provides information on maintenance of the equipment, which is beyond the scope of tools, equipment, personnel, or supplies normally available to using organizations.

b. Numbers in parentheses following nomenclature callouts on illustrations indicate quantity; numbers preceding callouts indicate preferred sequence.

1-2. Maintenance Forms and Records

Maintenance forms, records, and reports which are to be used by maintenance personnel at all maintenance levels are listed in and prescribed by TM 38-750.

1-3. Report of Equipment Publication Improvements

Report of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to Publications) and forwarded direct to Commanding General, U. S. Army Mobility Equipment Command, ATTN: AMSME-MPP, 4300 Goodfellow Boulevard, St. Louis, Mo. 63120.

Section II. DESCRIPTION AND DATA

1-4. Description

Refer to TM 5-3810-289-12 for complete description of the Model 22-BM Crane-Shovel.

1-5. Differences Between Models

This manual covers only the Model 22-BM Crane Shovel. No known unit differences exist for the model covered by this manual.

1-6. Tabulated Data

a. Crane-Shovel.

Manufacturer	Bucyrus-F Erie Co.
Model	22-BM
Type	Crawler mounted
Serial numbers	129566-129742 129905-130081 131944--131963 132052-132151

b. Engine.

Manufacturer	Cummins
Model	JN-6-1
Number of cylinders	4
Type of engine	Diesel
Cycle	4
Unit	Fan to fly wheel
Bore (in.)	4-1/in
Stroke (in.)	5 in.
Displacement (ea .in)	401
Compression ratio	16.3:1
Type drive	Mechanical
Type air intake	Naturally aspirated

Altitude-range (ft)	0-5000 + 107 F.
Rotation	Counter-clockwise
Cooling	Liquid
Fuel	fuel oil
Exhaust valve opens	62 BRC
Exhaust valve closes	44 ATC
Intake valve, opens	44 BTC
Intakes valve closes	40 ABC
(1) Governor.	
Make	Cummins
Type	Mechanical variable-speed

(2) Fuel Injector.

Make	Cummins
Model	PT
(3) Fuel pump.	
Make	Cummins
Model	G

c. Capacities

(1) Engine.

Crankcase	16 quarts
Oil filter	4 quarts
Fuel tank	50 gallons
Fuel filter	3 quarts
Coolant system	7 gallons

(2) Crane-shovel.

Transmission gear case	3 quarts
Machinery gear case	8 quarts
Propel gear case	2 quarts

**CHAPTER 2
DIRECT SUPPORT AND GENERAL SUPPORT
MAINTENANCE INSTRUCTIONS**

Section I. REPAIRS PARTS, SPECIAL TOOLS, AND EQUIPMENT

2-1. Tools and Equipment

Tools and equipment required to perform direct support and general support maintenance on the Crane-Shovel are listed in table 2-1. References to graphs and illustrations indicating the use of tools and equipment are listed in the table.

2-2. Special Tools and Equipment

Table 2-1 lists special tools and equipment required for direct support and general support maintenance on the crane-shovel.

2-3. Maintenance Repair Parts

Maintenance repair parts are listed and illustrated in TM 5-3810-289-35P.

Table 2-1. Special tools and equipment

Item	FSN or part No.	Paragraph reference	Use
Leakage tester	ST-990	3-13	Check injector cup for leaks.
Liner puller	ST-777	3-48	Pull cylinder liners from block.
	51203645416		
Camshaft bushing mandrel	ST-783	3-45	Replace camshaft bushing.
	67342		
Pulley assembly tool	ST-386	3-22	Assemble pulley.
Mandrel	ST430	3-2	Tachometer drive assembly installation.
Puller	ST-709	3-5	Governor weight shaft removal.
Liner bore tool	ST-676	3-45	Resurface cylinder liner counterbore.
	51330728366		
Adapter plate	ST-679	3-45	Used with cylinder liner counterbore tool.
Mandrel set block	ST491	3-29	Replace rocker liner bushings.
	34609991210		
Guide spacer	ST-707	3-47	Press in new solid guides in lead.
Belt tension gage	ST-968	3-36	Check belt tension.
Standard puller	ST-647	3-23	Remove accessory drive pulley.
Grinding machine	ST-685	3-46	Grind valve seats.
	Model-SG		
Seal driver	ST480	3-44	Install crankshaft oil seal.
Regrooving tool	ST483	3-43	Regroove top ring groove on piston.
Hold-down adapter	ST-1010	3-28	Hold-down injector sleeve for repair.
Plug gage	ST-504	3-43	Check piston pin bushing diameter.
Oil assembly tool	ST419	3-6	Assemble drive cover on fuel pump.
	51208968097		
Packing tool assembly	ST422	3-2	Install O-ring on throttle shaft of fuel pump.
Valve spring compressor	ST448	3-28	Remove valves and springs from cylinder head.
	51209813114		
Seat cutter pilot	ST-843	3-14	Guide seat cutter in drill press.
Grooving tool	ST-913	3-28	Regroove cylinder head.
	49109991499		
Holding tool	ST-923	3-28	Hold injector sleeve while testing for cracks.
Cup wrench	ST-934		Remove injector cup.
Guide puller	ST-667	3-46	Remove valve cross-head guides.
	51209813110		
Grooving tool	ST-597	3-28	Regroove cylinder head
Holding tool	ST-383	3-28	Hold injector sleeve while testing for cracks.
	51207664758		
Drill ream fixture	ST406	3-34	Ream dowel holes in flywheel housing.
Checking bar	ST409	3-45	(heck bore alignment.
Main bearing bore reamer	ST401	3-45	Ream out main bearing bore.
	51209991266		

Table 2-1. Continued

Item	FSN or part No.	Paragraph reference	Use
Valve tester	ST-417 49108980645		Check valves and seats for leakage.
Reamer driver	ST-219	3-45	Hard driver to turn main bearing bore reamer.
Valve seat insert kit	ST-257 51803453708	3-46	Hold and drive cutter when removing insert.
Sleeve expander	ST-297 51207664756	3-14	Seal upper portion of injector sleeve.
Ball joint vise	ST-302		Holds fuel pump for disassembly.
Injector seat cutter	ST-379 51207664757	3-14	Cut injector seat to give proper seat and tip protrusion.
Valve guide driver	ST-740	3-31	Install valve guides.
Cutter	ST-S25	3-14	Cut injector sleeve.
Piston ring compressor	ST-755	3-43	Install piston into skirt end of liner.
Chamfering tool	ST-861 49109991498	3-43	Chamfer tapered piston pin bushing bore.
Flange puller	ST-887	3-38	Pull crankshaft hub.
Wrench adapter	ST-669 M 1302A	3-47	Adapts torque wrench to locknuts of valve crossheads.
Spot facing tool	ST-542 51207664754	3-13	Repair inlet and drain connection surfaces of injector body.
Pump mounting plate	ST-546	3-2	Hold fuel pump for disassembly.
Gage block	ST-547 51206907949	3-45	Measure block counterbore depth.
Seal tool assembly	ST-558	3-42	Guides rear cover and seal into position.
Wear gage	ST-560 51209991209	3-43	Check ring groove wear.
Valve facing machine	ST684 Model-VS	3-31	Grind valves.
Lifting fixture	ST-756	3-28	Lift engine for mounting.
Sleeve rolling tool	ST-819 5130777529	3-14	Seal injector sleeve in lower seating area.
Packing tool assembly	ST-835 49109991505	3-2	Install preformed packing on throttle shaft of fuel pump.
Bead cutting tool	ST-839	3-14	Machine bead in sleeve seat area of bead.
Locating mandrel	ST-562	3-13	Measure connecting rod alinement.
Holding fixture	ST-569 51203645417	3-13	Hold fuel injector for repair.
Checking fixture	ST-570 51206907950	3-13	Check inject plunger seating for leaks
Holding fixture	ST-583 49207119307	3-28	Hold cylinder head for disassembly.
Cylinder liner driver	ST-594 51209991206	3-48	Cylinder liner installation.
Ring expander	ST-760 P407-R	3-43	Expands piston ring for installation.
Boring machine	ST-0526 PM 9000D	3-43	Bore out new piston ring for installation
Plate puller	ST-77S8	3-48	Used with cylinder liner puller.
Checking fixture	ST-561 49109777507	3-43	Check rod alinement.
Camshaft bushing driver.	ST-782 51209 39664	3-45	Replace camshaft bushing.
Mandrel and block	ST-605	3-43	Replace piston pin bushing.

Section II. TROUBLESHOOTING

2-4. General

This section provides information for diagnosing and correcting unsatisfactory operation or failure of the crane-shovel and its components.

2-5. Troubleshooting Chart

In chart 2-1, each malfunction listed is followed by probable causes of the trouble. The corrective action required is described opposite the probable cause.

Chart 2-1. Troubleshooting

Malfunction	Probable cause	Corrective action
1. Engine fails to start.	a. Injectors clogged	a. Replace injector (para 3-13)
2. Irregular firing of engine	b. Defective fuel pump	b. Replace fuel pump (para 3-2)
3. Engine smokes.	a. Injectors defective	a. Replace injector (para 3-13)
4. Engine knocks excessively	b. Piston rings worn	b. Replace piston rings (para 3-43)
5. Low or no lubricating oil pressure indication.	a. Injector defective	a. Replace injector (para 3-13)
6. Starter will not crank engine.	b. Piston rings worn	b. Replace piston ring (para 3-43)
7. Alternator not charging.	a. Injectors defective	a. Replace injectors (para 3-13)
8. Alternator output low or unsteady.	b. Main bearings	b. Replace plain bearings (para 3-44)
9. Batteries will not hold charge.	c. Connecting rod bearings	c. Replace connecting rod bearing- (para 3-43)
	a. Loose bearings	a. Replace bearings (para 3-37)
	b. Oil pump gear worn	b. Replace gears (para 3-37)
	Armature burned out.	Replace armature.
	Alternator inoperative.	Repair or replace alternate (para 3-1)
	Open or shorted silicon rectifier.	Replace rectifier (para 3-1)
	Alternator regulator not operating properly.	Refer to para 3-1.

Section III. GENERAL MAINTENANCE INSTRUCTIONS

2-6. General

This section contains general reference data and instructions for use by direct and general support maintenance as authorized by the maintenance allocation chart. It provides dimensions, tolerances, wear limits, torque data, and miscellaneous information required for maintenance of the crane-shovel.

2-7. Reference Data

a. Table 2-2 provides the following reference data:

- (1) Engine dimensions, tolerances, and wear limits.
- (2) Crane dimensions, tolerances, and wear limits.
- (3) Specific engine torque data.
- (4) General engine torque data.
- (5) Miscellaneous data.
- (6) Shovel dimensions, tolerances, and wear limits.

b. Paragraph 2-8 contains general maintenance instructions for the crane-shovel upper and lower works gears and bearings.

2-8. Maintenance of Gears and Bearings

a. *General.* Every power transmitting part on the crane-shovel revolving frame that is used in the work cycle is mounted on anti-friction bearings. This includes shafts and parts turning on shafts. Anti-friction bearings maintain concentricity, resulting in longer service life and lower maintenance.

Note. While the following instructions show ball bearings, the same procedure will apply to roller bearings.

b. Bearing Removal.

- (1) An arbor press is one of the best

dismounting tools and should be used wherever it is adaptable. Rest the bearing inner ring or both rings (never the outer ring only) against a pair of flat blocks of the same size and using a firm, steady pressure, force the shaft out.

- (2) Keep the shaft straight to avoid drainage from cocking.

(3) Where press is not adaptable, use a puller of a type which can be inserted behind the bearing inner race. Be sure that the jaws are set so that they will not slip over the inner race when pressure is applied. Exert an even pressure and pull straight.

(4) In cases where gears or other removable parts do not allow the puller to contact the bearing directly, use the puller on the parts directly back of the bearing.

(5) The use of a hammer is to be avoided unless other methods cannot be employed. Split sections of pipe or tubing, with welded lugs, can be used for shafts of various sizes. Alternating blows on opposite sides will prevent serious cocking. Be careful that pipe is free of chips that would be shaken into the bearing. In removing a bearing by pounding, care must be observed not to hit or scrape locknut threads on the shaft.

- (6) Cover bearings with cloth or paper as soon as they are removed.

Caution: Do not spin bearings before they are clean. If bearings are spun, dirt can cause scratch marks which may later lead to spalling.

c. Bearing Cleaning

- (1) Place bearings in a wire basket, so there is plenty of space for-cleaner to reach all parts and

immerse in a solvent. Tank should have a screened false bottom to prevent settings from being stirred up into the bearings. Agitate basket frequently until grease, oil or sludge is thoroughly loosened and can be flushed out.

(2) Bearings that contain especially heavy carbon deposits or hardened grease should be put in a basket by themselves and soaked in a separate container or solvent.

(3) Using a spray gun with air filter and a clean solvent, flush each bearing until all dirt or residue is removed. Turn one of the races slowly while flushing to help dislodge dirt from around balls and separator sockets.

(4) With dry, filtered air, blow solvent out of bearings, being careful not to spin by force of air. Since dry bearings rust quickly, lubricate them at once.

(5) Dip bearings in clean light spindle oil. Rotate them a few times and after draining the excess oil place them in a covered container for inspection.

d. Bearing Inspection. Discard bearings which show any of the following:

(1) Rusted balls or raceways. Usually caused by water passing worn or defective seals or by condensation inside housing.

(2) Fractured ring. Forcing a cocked bearing on or off a shaft will do this, as will too heavy a press fit.

(3) Worn, galled or abraded surfaces. Can be caused by too loose a fit, or bearing locked by dirt and turning on shaft or in housing.

(4) Broken or bent shields, seals or separator. Usually caused by improper uses of tools during mounting or removal.

(5) Badly discolored balls and races. Usually due to inadequate supply of lubricant. Moderate discoloration of balls and ball track is not a cause of discard.

(6) General feeling of roughness which remains unchanged by thorough cleaning, indicating damage to raceways or balls, such as indenting by dirt or pitting by corrosion.

(7) Catchy or rough feeling at one or more points which repeated flushing will not remove and which may be a spalled or fatigued spot. Thorough flushing is necessary to be sure it is not caused by dirt.

(8) Excessive looseness or end play, indicating lapping by dirt of abrasive in lubricant. If in

doubt, check against endplay feel of identical new bearing. Races and balls are dull gray when lapped by dirt.

(9) Any looseness or endplay which can be detected by hand feel is a cause for rejection only in the case of double row angular contact bearings.

e. Bearing Mounting.

(1) An arbor press is the most satisfactory tool for mounting bearings. Used properly, no Slows are struck and there is no danger of loosening shields or seals from this cause.

(2) Place the bearing on two flat blocks of equal size so that they contact the inner ring of the bearing. Then press shaft straight until the bearing is seated solidly against the shaft shoulder. Be sure that the blocks do not scrape or damage the threads if the shaft is threaded for a bearing locknut.

(3) Use of blocks that contact both rings is also good practice, provided the blocks are flat and the faces parallel.

(4) Where the distance from shaft end to bearing seat is short, a piece of pipe or tubing may be used. The pipe must be clean inside and out and the ends squared.

(5) In cases where a press is not available a piece of tubing may be used with a hammer. A plug in the tubing and a shield outside help to prevent jarring dirt into bearing. The hammer should be applied alternately at opposite points to avoid cocking and particular care should be taken when the bearing is started.

f. Gear Inspection and Repair.

(1) Clean gear with an approved cleaning solvent being particularly careful to clean out between gear teeth, and dry thoroughly. Inspect gear for cracks or breaks. Inspect key ways in gear hub. Be sure they are clean and open and in good condition. Check gear for warpage and if it is out of true more than the tolerance given in table 2-2 replace the gear. Inspect teeth for wear and if worn in excess of the tolerance given, replace the gear. Check teeth for any broken or nubbled teeth and also for other irregularities.

(2) Repair cracks or other defects in the gear by welding and grinding. If a considerable amount of welding is done on one side of the gear, check before reinstalling.

Table 2-2. Reference Data

Component points of measurement	Manufacturer's dimensions and tolerance in inches		Desired clearance		Maximum allowable wear and clearance
	Minimum	Maximum	Minimum	Maximum	
a. Cylinder Block					
Installed Camshaft	1.8745	1.8765			
Bushing Inside Diameter					1.8780
Camshaft Bushing Bore					
In Block No. 2-7	2.0035	2.0045			2.0055
No. 1 Bore for Thrust Plate	2.1245	2.1255			2.1265
Cylinder Liner Counterbore					
Inside Diameter	4.874	4.876			
Oversize Flange Linen	4.894	4.896			
Cylinder Liner Counterbore					
Depth	0.3092	0.3105			0.4023
Idler Gear Shaft	1.4975	1.4985			1.4995
Cylinder Block Height					
From Main Bearing Bore	15.122	15.124			15.114
From Top of Alinement Bar	13.0600	13.0615			13.0500
Cylinder Liner Counterbore Pt No.43782-A	0.0063	0.0077			
Shims Pt. No. 437824	0.0072	0.0088			
Pt. No. 43782-C	0.0081	0.0099			
Pt. No. 114552	0.018	0.022			
Pt. No. 114523	0.028	0.034			
Pt. No. 124455	0.056	0.068			
Pt. No. 124569	0.093				
Cylinder Liner Protrusion	0.004	0.006			
Liner-to-Block Clearance	Liner may contact block if it does not force liner out of round				
Liner Bore					
Diametrical	0.005	0.009			
Lower Liner Bore:					
Inside Diameter	4.619	4.21			
Main Bearing Bore	4.1240	4.1250			4.1255
Tappet Bore in Block:					
Injector	1.3120	1.3130			1.3145
Valve	1.1870	1.1880			1.1895
Main Bearing Cap Fit In Block	0. 4.002	4.004			0.001
b. Cylinder Liner.					
Cylinder Liner (ID)—Cast Iron	4.1250	4.1260			4.1300
Cylinder Liner Protrusion	0.004	0.006			
c. Idler Gear.					
Idler Gear Bushing (ID)	2.125	2.126			2.127
Gear Hub Bushing (ID.)	1.500	1.501			1.502
Idler Gear Hub	2.1225	2.1235			2.1215
Idler Thrust Washers					
Part Nos.:					
68631	0.096	0.106			0.091
68632	0.061	0.063			0.059
68633-1	0.192	0.194			0.190
d. Bearings.					
Standard Bearing Shell Thickness					
Main Bearing	0.1231	0.1236			0.1216
Connecting Rod	0.0722	0.0727			0.0710
Journal Oil Clearance					
Main	0.0018	0.0048			0.0068
Connecting Rod		0.0020	0.0045		0.0080
Crankshaft Thrust Bearings--					
Part No. 150310	0.151	0.153			
Crankshaft End Clearance	004	0.015			0.022
Vibration Dampers:					
Eccentricity and Wobble		0.030			0.030

Table 2-2. Reference Data-Continued

Component points of measurement	Manufacturer's dimensions and tolerance in inches		Desired clearance		Maximum allowable wear and clearance
	Minimum	Maximum	Minimum	Maximum	
Connecting Rod Dimensions:					
Crank pin Bore	2.7725	2.7730			
Out of Round					0.0015
Piston Pin Bushing	1.5000	1.5005			1.5015
Connecting Rod Twist:					
Without Bushing					0.020
With Bushing					0.010
Connecting Rod Length.....	9.498	9.500			
Bore Misalignment					0.001
Piston and Piston Rings:					
Piston Ring Gap (new or reconditioned liner)					
Pt. No. 68788	0.013	0.023			
Pt. No. 109410	0.013	0.023			
Pt. No. 144980	0.013	0.023			
Pt. No. 126480	0.013	0.025			
Pt. No. 146140	0.015	0.055			
Standard Piston Skirt Diameter (700 F)					
130360, 130500, 11738, 144840, 149200, 168430, compression ratio 16.3:1 Gage Point BC	4.1180	4.1190			4.1150
Piston Pin Bore	1.4988	1.4990			1.5000
Piston Pin Diameter	1.4988	1.4990			1.4978
Pistons and Rings Oversize	0.020	0.030			0.040
e. Camshaft.					
Camshaft Journal Diameter:					
No. 1 Journal only.....	1.747	1.748			1.746
All Other Journals.....	1.872	1.873			1.871
Camshaft Lobe Lift					
f. Injection Spec BTC 64°, A r 19°. Valve Overlap 880. Exhaust Opens BBC 620. Intake Opens BTC 440°. Exhaust Closes ATC 440°. Intake closes ABC 400. Valve Lobe Lift 0.251 in. Injection Lobe Lift 0.112 in.					
g. Gear Cover.					
Accessory Drive Bushing I.D.:					
139810 Std.....	1.314	1.319			1.3205
139811 0.010 in.....	1.304	1.309			1.3105
139812 0.020 in.....	1.294	1.299			1.3005
h. Cylinder Head.					
Crosshead Guide Dimensions:					
Solid type (OD.).....	0.3750	0.3755			0.3740
Head Height	5.000	5.010			4.970
i. Valve Seats and Insert					
Valve Seat Insert Run-Out.....		0.002			
Oversize Diameter Std. Depth Std. Insert O.D. 1.4300/1.4305. Cylinder Head I.D. 1.427/1.428. Insert Thickness 0.156/0.161.					
l. Valve Crossheads.					
Crosshead Dimensions:					
Solid Stem.....	0.3708	0.3713			0.370
k. Valves, Guides and Springs.					
Valves Stem Dimensions:					
Four-valve Head	0.3400	0.3410			0.3390
Valve Guide I.D.:					
Four-valve Head.....	0.3425	0.3432			0.3442
Valve Guide Protrusion:					
Four-valve Head.....	1.240	1.260			

Table 2-2. Reference Data-Continued

Component points of measurement	Manufacturer's dimensions and tolerance in inches		Desired clearance		Maximum allowable wear and clearance
	Minimum	Maximum	Minimum	Maximum	
Valve Spring Data					
Free Length is 2.364. Pounds Force Required to Compress 105 Lbs. 50 117 Lbs. No. of Coils 9 1/2. Wire Diameter 0.148. Length 1.610.					
1. Rocker Levers and Cover.					
Rocker Lever Bushing (I.D.)	1.1245	1.1275			1.1285
Rocker Lever Shaft (O.D.)	1.1230	1.1235			1.1220
m. Push Tubes					
Valve Push Tube:					
Ball End	0.624	0.625			
Socket End (Spherical I.D.)0.4995	0.5005			
Injector Push Tube					
Ball End	0.685	0.687			
Socket End (Spherical I.D.)	0.4995	0.5005			
n. Tappets.					
Injector Tappet Assembly:					
Body (O.D.)	1.3100	1.3110			1.3090
Roller (O.D.)	1.1230	1.1250			1.1210
Roller (I.D.)	0.5655	0.5665			0.5675
Roller Pin (O.D.)	0.5620	0.5626			0.5610
Roller, Side Clearance	0.0050	0.0170			0.0220
Roller Concentricity Assembled		0.0005			
Roller Squareness Assembled		0.0010			
Valve Tappet Assembly:					
Body (O.D.)	1.1850	1.1860			1.1840
Roller (O.D.)	1.0610	1.0630			1.0590
Roller (I.D.)	0.5030	0.5040			0.5050
Roller Pin (O.D.)	0.4995	0.5000			0.4985
Roller Side Clearance	0.0080	0.0220			0.0270
Roller Concentricity Assembled		0.0010			
Roller Squareness Assembled		0.0010			
o. Lubricating Oil Pump.					
Lubricating Oil Pump Dimensions:					
Idler and Drive Shaft Bushing (I.D.)	0.6165	0.6175			0.6185
Idler and Drive Shaft (O.D.)	0.6150	0.6155			0.6140
Idler Gear Bushings (I.D.)	0.9925	0.9935			0.9945
Idler Gear Shaft (O.D.)	0.9900	0.9910			0.9890
Idler and Driven Gear (O.D.)	1.8320	1.8330			1.8310
Gear Pockets (Minor I.D.)	1.8400	1.8420			1.8430
Gear Pocket Depth	1.6230	1.6250			1.8430
Balance Drive Shaft		0.8095			0.8105
Balance Drive Shaft Bushing	0.8145	0.8150			0.8170
Idler Gear Thrust Washer	0.0610	0.0630			
Balance, Drive Gear Thrust Washer	0.600	0.620			
Lube Pump Drive Shaft Bushing	0.6165	0.6175			0.6185
p. Pressure Regulator.					
Pressure Regulator Dimensions:					
Low Pressure (I.D.)	0.621	0.626			0.627
Low Pressure (O.D.)	0.740	0.741			0.739
High Pressure (Large Outside)	0.740	0.741			0.739
High Pressure (Small Outside)	0.615	0.617			0.614
Housing Bore	0.740	0.741			0.739
Spring Load @ 2.055 in	16.4 lb.	18.01 lb.			14.0 lb.