

TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT SUPPORT, AND GENERAL SUPPORT,

MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

SEMITRAILER, LOW BED: WRECKER,
12-TON, 4- WHEEL

M269 (2330-395-1876)

M269A1 (2330-542-2980)

M270 (2330-395-1877)

M270A1 (2330-289-7515)

This copy is a reprint which includes current
pages from Change 1.

TECHNICAL MANUAL
 No. 9-2330-220-24P

HEADQUARTERS
 DEPARTMENT OF THE ARMY
 Washington, D. C., 20 August 1973

**Organizational, Direct Support and General Support
 Maintenance Repair Parts and Special Tools List
 SEMITRAILER, LOW BED: WRECKER, 12-TON, 4-Wheel**

M269 (2330-395-1876)

M269A1 (2330-542-2980)

M270 (2330-395-1877)

M270A1 (2330-289-7515)

Current as of 1 January 1973

		<i>Paragraph</i>	<i>Page</i>
SECTION	I. INTRODUCTION	1-7	6
Group	II. REPAIR PARTS LIST		10
	06. ELEXTRICAL SYSTEM	Figure	
	0609 Stoplight-tailight	8	10
	Blackout stoplight	9	11
	Directional light	10	11
	Composite marker light	11	12
	Clearance light	12	12
	0613 Wiring harnesses	NI	14
Group	11. AXLE		
	1100 Axle assembly	13	20
	Axle trunnion	14	20
Group	12. BRAKES		
	1202 Service brakes	15	21
	Service brakes	16	23
	1204 Master hydraulic cylinder	17	25
	Hydraulic lines and fittings	22	26
	1206 Slack adjuster	18	26
	1208 Air chamber	17	27
	Air chamber	19	28
	Air filter	20	30
	Airbrake system lines and fittings	21	30
	Air / hydraulic brake system	22	32
	Air reservoir	NI	34
	Air hose coupling and tube connector	23	34
	Emergency-relay valve	24	36

♦ This manual supersedes SM ORD 9 SNL G802 / TO 36A9-9-1-104, 28 March 1957.

			Figure	Page
Group	13.	WHEELS, HUBS AND DRUMS		
		1311 Hub and drum assembly	25	36
		Hub and drum assembly	26	38
		Wheels	27	40
		1313 Tires and Tubes	27	40
Group	15.	FRAME		
		1501 Chock blocks	28	40
		1504 Spare wheel and tire carrier	29	41
		1507 Landing gear	30	42
		Landing leg gear box, right	31	43
		Landing gear, right	32	44
		Landing gear, left	33	45
		Hand crank ratchet	34	47
Group	16.	SPRINGS		
		1601 Spring seat and bearings	35	48
		Spring assembly	36	49
		1605 Torque rods and brackets	37	50
Group	18.	BODY		
		1808 Stowage box	38	51
		Stowage box	NI	52
		1810 Stake and connecting line	39	53
		1810 Deck installation	NI	54
Group	22.	MISCELLANEOUS ACCESSORIES		
		2202 Reflectors	NI	57
		2210 Vehicular data plates	NI	58
SECTION	III.	SPECIAL TOOLS LIST		59
Group	26.	TOOLS AND EQUIPMENT		
		2604 Special tools	40	59
		Special tools	41	59
SECTION	IV.	FEDERAL STOCK NUMBER AND PART NUMBER INDEX		80




Figure 6. Semitrailer, low bed: wrecker, M270A1-left front view.




Figure 7. Semitrailer, low bed: wrecker, M269A1 and M270A1-right view-typical.

SECTION I

INTRODUCTION

1. Scope

This manual lists repair parts, special tools and test equipment required for the performance of organizational, direct support and general support maintenance of the 12-ton, 4-wheel low bed wrecker semitrailers, M269, M269A1, M270 and M270A1.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Repair Parts-Section II. A list of repair parts authorized for the performance of maintenance at the organizational, direct support and general support maintenance level in figure and item number sequence.

b. Special Tools-Section III. A list of special tools and test equipment authorized for the performance of maintenance at the organizational, direct support and general support levels.

c. Federal Stock Number and Reference Number Index-Section IV. A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alpha-numeric sequence, of all reference numbers appearing in the listing. Federal stock numbers and reference numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

The following provides an explanation of columns in the tabular lists.

a. Source, Maintenance, and Recoverability Codes (SMR).

(1) *Source Code.* Source Codes are assigned to support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

<i>Code</i>	<i>Definition</i>
PA	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance purpose because essentiality dictates that a minimum quantity be available in the supply systems.
PC	Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE	Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.

<i>Code</i>	<i>Definition</i>
PF	Support equipment which will not be stocked but which will be centrally procured on demand.
PG	Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD	An item of depot overhaul / repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF	An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance.
KB	Item included in both a depot overhaul / repair kit and a maintenance kit.
MO	Item to be manufactured or fabricated at organizational level.
MF	Item to be manufactured or fabricated at the direct support maintenance level.
MH	Item to be manufactured or fabricated at the general support maintenance level.
MD	Item to be manufactured or fabricated at depot maintenance level.
AO	Item to be manufactured or fabricated at depot maintenance level.
AF	Item to be assembled at the direct support maintenance level.
AH	Item to be assembled at the general support maintenance level.
AD	Item to be assembled at depot maintenance level.
XA	Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly.
XB	Item is not procured or stocked. If not available through salvage, requisition.
XC	Installation drawing, diagram, instruction sheet, field service drawing, that is identified by manufacturers' part number.

Note

Cannibalization or salvage may be used as a source of supply for any items above except those coded XA.

(2) *Maintenance Code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to **USE** and **REPAIR** support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

USE (THIRD POSITION): The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance: