


TECHNICAL MANUAL

**OPERATOR'S, UNIT AND DIRECT
SUPPORT MAINTENANCE MANUAL**

**KITCHEN, FIELD,
TRAILER MOUNTED**

MKT-75	NSN: (7360-00-138-7782)	EIC: YBC
MKT-75A	NSN: (7360-01-092-0470)	EIC: YBL
MKT-82	NSN: (7360-01-155-6020)	EIC: YBM
MKT-85	NSN: (7360-01-214-1176)	EIC: YBT
MKT-85S	NSN: (7360-01-246-4646)	EIC: (Air Force Only)
MKT-90	NSN: (7360-01-313-2238)	EIC: YCF
MKT-95	NSN: (7360-01-417-4635)	EIC: YCG
MKT-99	NSN: (7360-01-483-8617)	EIC: N/A



DISTRIBUTION STATEMENT A – Approved for public release; distribution is unlimited.

*This manual supersedes TM 10-7360-206-13, 1 June 1984, including all changes.

HEADQUARTERS, DEPARTMENTS
OF THE ARMY AND THE AIR FORCE
WASHINGTON, D.C., 31 March 2002

TECHNICAL MANUAL

**OPERATOR'S, UNIT, AND DIRECT
SUPPORT MAINTENANCE MANUAL**

KITCHEN, FIELD, TRAILER MOUNTED

MKT-75	NSN: (7360-00-138-7782)	EIC: YBC
MKT-75A	NSN: (7360-01-092-0470)	EIC: YBL
MKT-82	NSN: (7360-01-155-6020)	EIC: YBM
MKT-85	NSN: (7360-01-214-1176)	EIC: YBT
MKT-85S	NSN: (7360-01-246-4646)	EIC: (Air Force Only)
MKT-90	NSN: (7360-01-313-2238)	EIC: YCF
MKT-95	NSN: (7360-01-417-4635)	EIC: YCG
MKT-99	NSN: (7360-01-483-8617)	EIC: N/A

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter together with DA Form 2028 (Recommended Changes to Publications and Blank Forms), located in the back of this manual, directly to: Commander, U.S. Army Soldier and Biological Chemical Command, ATTN: AMSSB-RIM-E(N), Kansas Street, Natick, MA 01760-5052. You may also send in your recommended changes via electronic mail directly to amssb-rim-e@natick.army.mil. A reply will be furnished to you. Instructions for sending an electronic 2028 may be found at the back of this manual immediately preceding the hard copy 2028.

Air Force - Mail AFTO Form 22 directly to: Commander, Warner Robins Air Logistics Center, ATTN: TILTA, 420 Second St., Robins Air Force Base, GA 31098-1640 in accordance with TO-00-5-1.

DISTRIBUTION STATEMENT A – Approved for public release. Distribution is unlimited.

* This manual supersedes TM 10-7360-206-13, dated 1 June 1984, including all changes.

HEADQUARTERS, DEPARTMENT OF THE ARMY

TABLE OF CONTENTS

WP Sequence No.

WARNING SUMMARY

HOW TO USE THIS MANUAL

CHAPTER 1 – DESCRIPTION AND THEORY OF OPERATION

SCOPE	0001 00
MAINTENANCE FORMS RECORDS AND REPORTS	0001 00
REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIRS)	0001 00
WARRANTY INFORMATION	0001 00
CORROSION PREVENTION AND CONTROL (CPC)	0001 00
DESTRUCTION OF ARMY MATERIEL TO PREVENT ENEMY USE.....	0001 00
NOMENCLATURE CROSS-REFERENCE LIST	0001 00
LIST OF ABBREVIATIONS/ACRONYMS	0001 00
SAFETY, CARE AND HANDLING, WARNINGS, CAUTIONS AND NOTES	0001 00
EQUIPMENT CHARACTERISTICS, CAPABILITIES AND FEATURES.....	0001 00
LOCATION AND DESCRIPTION OF MAJOR COMPONENTS	0002 00
EQUIPMENT DATA	0002 00
COMMON TOOLS AND EQUIPMENT	0002 00
THEORY OF OPERATION	0003 00

CHAPTER 2 - OPERATOR INSTRUCTIONS

GENERAL	0004 00
CONTROLS, INDICATORS, AND LABELS/INSTRUCTION PLATES	0004 00
OPERATION UNDER USUAL CONDITIONS.....	0005 00
SITING REQUIREMENTS	0005 00
UNPACKING THE MKT	0005 00
MULTIPLE KITCHEN INSTALLATION	0005 00
PREPARATION FOR MOVEMENT	0005 00
PREPARATION FOR STORAGE	0005 00
OPERATION UNDER UNUSUAL CONDITIONS	0006 00

CHAPTER 3 – OPERATOR TROUBLESHOOTING PROCEDURES

TROUBLESHOOTING PROCEDURES.....	0007 00
---------------------------------	---------

CHAPTER 4 – OPERATOR MAINTENANCE INSTRUCTIONS

OPERATOR MAINTENANCE.....	0008 00
OPERATOR PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)	0009 00

CHAPTER 5 – UNIT TROUBLESHOOTING PROCEDURES

UNIT TROUBLESHOOTING PROCEDURES	0010 00
---------------------------------------	---------

CHAPTER 6 – UNIT MAINTENANCE INSTRUCTIONS

LUBRICATION REQUIREMENTS	0011 00
SERVICE UPON RECEIPT OF MATERIAL AND REPAIR AND SPECIAL TOOLS	0012 00
INSTALLATION OF MKT-I IMPROVEMENT KIT COMPONENTS	0013 00
UNIT PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)	0014 00
LUBRICATION – TENTPOLE ASSY	0015 00
LUBRICATION-CORNER POST ASSY.....	0016 00
UNIT MAINTENANCE GENERAL REPAIR INSTRUCTIONS.....	0017 00

TABLE OF CONTENTS - Continued

WP Sequence No.

REPAIR ROOF VENT & SCREEN ASSY-12 VENTS.....	0018 00
REPAIR ROOF VENT & SCREEN ASSY - 6 VENTS.....	0019 00
REPAIR SKYLIGHT OPERATOR - 6 VENTS.....	0020 00
REPAIR AND REPLACE CORNER STRUT ASSEMBLY.....	0021 00
REPAIR ROOF FRAME ASSEMBLY MKT-90, MKT-95, MKT-99.....	0022 00
REPAIR ROOF JACK ASSEMBLY MODELS 400A-1, PMF-81A, AND ALS516-00.....	0023 00
REPAIR ROOF JACK ASSEMBLY, CAGEC 81337 P/N 5-13-4600.....	0024 00
REPAIR OR REPLACE TENTAGE ASSEMBLIES.....	0025 00
REPLACEMENT OF THE CABINET ASSEMBLIES.....	0026 00
REPAIR LADDER ASSEMBLY.....	0027 00
REPAIR TIE DOWN STRAP ASSEMBLIES.....	0028 00
REPAIR PLATFORM AND RAMP ASSEMBLY.....	0029 00
REPAIR SHOCK ABSORBER ASSEMBLY.....	0030 00
REPLACE LEVELING JACK ASSEMBLIES MODELS ALS516-90, 5000L, ETC.....	0031 00
REPAIR OF WIRING HARNESS AND HOOK TIE DOWN ASSEMBLY.....	0032 00
REPAIR TENT POLE ASSEMBLY.....	0033 00
REPAIR CORNER POST ASSEMBLY.....	0034 00
REPLACE Z-BAR LATCH AND DIAGONAL BRACE.....	0035 00
REPLACE BENCH LEVEL ASSEMBLY.....	0036 00
REPAIR INSULATED LIQUID DISPENSER.....	0037 00
REPAIR MOUNTED CAN OPENER.....	0038 00
REPLACE MOUNTED CAN OPENER BRACKET.....	0039 00

CHAPTER 7 – DIRECT SUPPORT MAINTENANCE INSTRUCTIONS

DIRECT SUPPORT MAINTENANCE INSTRUCTIONS.....	0040 00
REMOVAL OF RIVETS.....	0041 00
REPAIR ROOF VENT & SCREEN ASSEMBLY - KITCHENS WITH 12 ROOF VENT ASSY'S.....	0042 00
REPLACE ROOF VENT & SCREEN ASSEMBLY - KITCHENS WITH 6 ROOF VENT ASSY'S.....	0043 00
REPAIR ROOF VENT & SCREEN ASSEMBLY - KITCHENS WITH 6 ROOF VENT ASSY'S.....	0044 00
REPAIR ROOF FRAME ASSEMBLY.....	0045 00
REPAIR ROOF JACK ASSEMBLY CAGEC 81337, P/N 5-13-4600.....	0046 00
REPAIR TENTAGE ASSEMBLIES.....	0047 00
REPAIR CABINET ASSEMBLIES.....	0048 00
REPAIR LEVELING JACK ASSEMBLY, P/N 5-13-4611, CAGEC 81337.....	0049 00
REPAIR LADDER ASSEMBLY.....	0050 00
REPAIR PLATFORM AND RAMP ASSEMBLY.....	0051 00
REPAIR CORNER POST ASSEMBLY.....	0052 00
REPAIR CONDIMENT TRAY ASSEMBLY.....	0053 00

CHAPTER 8 - SUPPORTING INFORMATION

REFERENCES.....	0054 00
MAINTENANCE ALLOCATION CHART.....	0055 00
COMPONENTS OF END ITEMS (COEI) LIST & BASIC ISSUE ITEMS (BII) LIST.....	0056 00
ADDITIONAL AUTHORIZATION LIST.....	0057 00
EXPENDABLE AND DURABLE ITEMS LIST.....	0058 00
MKT-I IMPROVEMENT KIT COMPONENT LISTING.....	0059 00

ALPHABETICAL INDEX..... INDEX 1

HOW TO USE THIS MANUAL

This manual contains General Information, Operating Instructions, Operator Preventive Maintenance Checks and Services (PMCS), Troubleshooting, and Maintenance/Repair instructions for the Mobile Kitchen Trailer - Mounted (MKT).

Chapter 1 contains introductory information on the MKT and its associated equipment as well as a Theory of Operation. Chapter 2 includes operating instructions under usual and unusual conditions. Chapter 3 contents include operator troubleshooting, PMCS, and service procedures. Chapter 4 contains Operator Maintenance instructions. Chapter 5 contains Unit Troubleshooting procedures. Chapter 6 contains Unit Maintenance Procedures. Chapter 7 covers Direct Support Maintenance Procedures. Chapter 8 contains references and other supporting information. Chapter 8 also includes the Repair Parts and Special Tools List (RPSTL) which identifies those parts or tools which are unique to the operation and maintenance of this equipment.

Manual Organization and Page Numbering System. The manual is divided into six major chapters that detail the topics mentioned above. Within each chapter are work packages covering a wide range of topics. Each work package is numbered sequentially starting at page 1. The work package has its own page numbering scheme and is independent of the page numbering used by other work packages. Each page of a work package has a page number of the form XXXX YY-ZZ where XXXX is the work package number (e.g. 0010 is work package 10) and YY is the revision number for that work package and ZZ represents the number of the page within that work package. A page number such as 0010 00-1/2 blank means that page 1 contains information but page 2 of that work package has been intentionally left blank.

Finding Information. The Table of Contents permits the reader to find information in the manual quickly. The reader should start here first when looking for a specific topic. The Table of Contents lists the topics contained within each chapter and the Work Package Sequence Number where it can be found.

Example: If the reader were looking for instructions on "Preventive Maintenance Checks and Services", which is a Operator Maintenance topic, the Table of Contents indicates that Operator Maintenance information can be found in Chapter 3. Scanning down the listings for Chapter 3, "Preventive Maintenance Checks and Services" information can be found in WP 0010 00 (i.e. Work Package 10).

An Alphabetical Index can be found at the back of the manual, and lists specific topics with the corresponding work package.

MOBILE KITCHEN TRAILER (MKT)
GENERAL INFORMATION

SCOPE

This Technical Manual contains operation as well as preventative and corrective maintenance instructions for the Mobile Kitchen Trailer (MKT) (1) and its associated components consisting of an ice chest (2), insulated food containers (3), insulated liquid dispensers (4), a moveable cabinet (5), field tables (6), a griddle grease splash guard assembly (7), netting and curtains (8), strut, fabric holdout assemblies (9), tent pole assemblies (10), fuel cans (11), tray-pack lifter (12), serving tray-pack lifter (13), tray-pack warmers (14) hand can opener (15), mounted can opener (16), and water containers (17).

Type of Manual: Operator's, Unit, and Direct Support Maintenance.

Model Numbers and Equipment Names:

MKT-75 - Kitchen, Field, Trailer Mounted
MKT-75A - Kitchen, Field, Trailer Mounted
MKT-82 - Kitchen, Field, Trailer Mounted
MKT-85 - Kitchen, Field, Trailer Mounted
MKT-85S - Kitchen, Field, Trailer Mounted (Air Force Only)
MKT-90 - Kitchen, Field, Trailer Mounted
MKT-95 - Kitchen, Field, Trailer Mounted
MKT-99 - Kitchen, Field, Trailer Mounted

Purpose of Equipment: Feeding of personnel in the field.

