


TECHNICAL MANUAL

**DIRECT SUPPORT AND GENERAL SUPPORT
MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS
LISTS (INCLUDING DEPOT MAINTENANCE REPAIR
PARTS AND SPECIAL TOOLS)**

**CENTRAL OFFICE, TELEPHONES,
MANUAL
AN/TTC-7 (FSN 5805-503-1210) AND
AN/TTC-7A (FSN 5805-820-9549)**

**This copy is a reprint which includes current
pages from Changes 1.**



**Direct Support and General Support Maintenance
Repair Parts and Special Tools Lists (Including
Depot Maintenance Repair Parts and Special Tools)**

**CENTRAL OFFICE, TELEPHONES, MANUAL
AN/TTC-7 (FSN 5805-503-1210) AND
AN/TTC-7A (FSN 5805-820-9549)**

Current as of March 1973

	Paragraph	Page
SECTION I. INTRODUCTION		
Scope	1-1	1
General.....	1-2	1
Explanation of columns.....	1-3	1
Special information	1-4	3
Location of repair parts	1-5	3
Abbreviations (Not applicable)	1-6	4
Reporting of equipment publication improvements.....	1-7	4
II. REPAIR PARTS LIST		6
Main Distributing Frame, Telephone TA-257/TTC		8
Switchboard, Telephone, Manual SB-249/TTC; SB-249A/TTC		9
Telephone Circuit, Line Relay TA-223/TTC; TA-223A/TTC		16
Telephone Circuit, Trunk Relay TA-226/TTC; TA-226A/TTC		18
Test Set, Telephone TS-1361/G.....		20
Switchboard, Telephone, Manual SB-1398/GTA-14(V).....		21
Panels, Power Distribution SB-1399/GTA-14(V) and SB-1032/TTC.....		34
Telephone Circuit Line Relay TA-452/GTA-14(V).....		35
Telephone Circuit Trunk Relay TA-453/GTA-14(V).....		37
Main Distributing Frame Telephone TA-454/GTA-14(V)		38
SECTION III. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (Not applicable)		
IV. INDEX-FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS- REFERENCE TO FIGURE AND ITEM NUMBER.....		40

*This manual supersedes TM 11-5805234-35P, 29 July 1963, including all changes.

SECTION I

INTRODUCTION

1-1. Scope

This manual lists repair parts and special tools required for the performance of direct support, general support, and depot maintenance of the AN/TTC-7 and AN/TCC-7A. The PCCN for the equipment is GCWAAP for all models.

1-2. General

This repair parts and special tools list is divided into the following sections:

a. *Repair Parts List-Section II.* A list of repair parts authorized for the performance of maintenance at the direct support, general support, and depot level. This repair parts list is arranged in alphabetical order.

b. *Special Tools, Test and Support Equipment - Section III.* Not applicable.

c. *Index-Federal Stock Number and Reference number Cross-Reference to Figure and Item Number-Section IV.* A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all reference numbers appearing in the listings. Federal stock number and reference numbers are cross-referenced to each illustration figure and item number or reference designation appearance.

1-3. Explanation of Columns

The following provides an explanation of columns found in the tabular list.

a. Source, Maintenance, and Recoverability Codes (SMR).

(1) *Source code.* Indicates the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are—

<i>Code</i>	<i>Explanation</i>
-	Item procured and stocked for anticipated or known usage.
PB	Item procured and stocked for insurance purposes because essentiality dictates that a minimum quantity be available in the supply systems.
PC	Item procured and stocked and which other Code Explanation wise would be coded PA

<i>Code</i>	<i>Explanation</i>
-	except that it is deteriorative in nature.
PD	- Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
PE	- Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities.
PF	- Support equipment which will not be stocked but which will be centrally procured on demand.
PG	- Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which because of probable discontinuance or shutdown of production facilities would prove uneconomical to reproduce at a later time.
KD	- An item of depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair.
KF	- An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or direct support or general support levels of maintenance.
KB	- Item included in both a depot overhaul/repair kit and a maintenance kit.
MO	- Item to be manufactured or fabricated at organizational level.
MF	- Item to be manufactured or fabricated at direct support maintenance level.
MH	- Item to be manufactured or fabricated at general support maintenance level.
MD	- Item to be manufactured or fabricated at depot maintenance level.
AO	- Item to be assembled at organizational level.
AF	- Item to be assembled at direct support maintenance level.
AH	- Item to be assembled at general support maintenance level.